



Pencil Lite

Manual Guide


For all instruction manual, visit deqster.de/downloads



Packaging List

- 1 DEOSTER Pencil Lite
- 1 User Manual
- 1 Type C Cable
- 2 Pen Tips


Specification




2

Instructions

Let your creativity run wild with your DEOSTER Pencil Lite! It's perfect for drawing and writing on your iPad.



1. You can turn the Pencil Lite on and off with a double tap on the top. The display shows the battery charge in percent.



2. For optimal battery life, the percentage display turns off after about 4 seconds. Tap the upper part of the Pencil once to reactivate the display.

Working mode:



Energy saving mode:




3


3. A full battery charge is indicated via the display. If you remove the charging cable, the display turns off.



4. The pen tips of the Pencil Lite are replaceable. Carefully rotate the pen tip to change it.



5. The Pencil Lite is magnetic and can be attached to your device. (Please note the compatibility to the used iPad).



*Note: Wireless charging is not supported.

*To use the Pencil, the iPad's operating system must be updated to iOS 12.2 or higher.

*If the iPad was previously paired with an Apple Pencil, this pairing should be removed before using the Pencil.

*If an Apple Pencil is connected, it must be disconnected before DEOSTER Pencil can be used.

4

Compatible device

Only compatible with Apple iPad/ iPad Air versions of 2018 and later. Not support iPhone, Android, Microsoft devices, earlier versions of iPad.

Name/size	Model
iPad 6 / 9.7-inch(2018)	A1954
iPad 7 / 10.2-inch(2019)	A2197 / A2198 / A2200
iPad 8/10.2-inch(2020)	A2270 / A2428 / A2429 / A2430
iPad 9/10.2-inch(2021)	A2602 / A2603 / A2604 / A2605
iPad 10/10.9-inch(2022)	A2696 / A2757 / A2777
iPad mini 5/7.9-inch(2019)	A2133 / A2124 / A2126 / A2125
iPad mini 6/8.3-inch(2021)	A2567 / A2568 / A2569
iPad Air 3/10.5-inch(2019)	A2152 / A2123 / A2153 / A2154
iPad Air 4/10.9-inch(2020)	A2316 / A2324 / A2325 / A2072
iPad Air 5/10.9-inch(2022)	A2588 / A2589 / A2591
iPad pro 11-inch(2018)	A1980 / A2013 / A1934 / A1979
iPad pro 3/12.9-inch(2018)	A1 876 / A2014 / A1895 / A1983
iPad pro 2/11-inch(2020)	A2228 / A2231 / A2068 / A2030
iPad pro 4/12.9-inch(2020)	A2229 / A2233 / A2069 / A2232
iPad pro 3/11-inch(2021)	A2377 / A2459 / A2301 / A2460
iPad pro 5/12.9-inch(2021)	A2378 / A2461 / A2379 / A2462
iPad pro 4/11-inch(2022)	A2759 / A2435 / A2761 / A2762
iPad pro 6/12.9-inch(2022)	A2436 / A2766 / A2764 / A2437

Product Specification

Product Name DEOSTER Pencil Lite

Main Functions Drawing, Writing, Notes

Using Hours 10hours

Charging Hours 35min

Sleeping Protect 5 Mins do not using Pencil will turn it off

Materials Aluminum, POM plastic

Measurement Φ 1.5mm (pen nib)
 Φ 9.0mm (pen body)

DEOSTER GmbH Friesenweg 5H, 22763 Hamburg
Email: hullo@deqster.de

5