
Overview

Firmware update tool is an application used to update monitor firmware.

Firmware Update Pre-requisites

1 Connect the monitor to a power source, during the firmware update process.



2 Make sure there is only ONE video input source, e.g. DisplayPort or HDMI, from the computer to the monitor.

NOTE: Ensure that all other video cables between the monitor and the computer are unplugged.

3 Connect the USB Type-C to Type-A cable directly between the monitor and your computer. Do not use any other device between this connection.




NOTE: Ensure that other USB cables and USB devices between the monitor and the computer are unplugged.



U

NOTE: Disconnect all other monitors from the notebook or desktop. This will ensure that only one display is connected while conducting firmware update.

NOTE: It is recommended to update the firmware with a notebook as the monitor screen may go blank during the firmware update process.



NOTE: Do not unplug the cables till the updating process finishes.

NOTE: Please disable sleep mode before you launch the firmware update.


NOTE: Update one monitor at a time. Do not conduct firmware update on multiple monitors at a given time.

Installation

Install via GUI

1 Double-click **deb file (e.g. Dell_U2424H_FWUpdate_M3B102_Ubuntu.deb)** on the desktop and then click the **Install** button in Ubuntu software center.


Ubuntu	i söftware Center	♡≣;⊠⊡40\$
Ø	Alsofrave Britery Progres	
	dell-monitor-firmware-update-utility	
	Only install this file if you trust the origin.	Install
		No screenshot available
× • •	Version dell'anosto-firmure-pydate-utility 2.0.0.24 Total data « 4.6MB when installed Ucense Ushcom Ushcom	
		English • Most helpful first •
Ŧ	This app has not been reviewed yet You need to install this leff or syste, can review it	
Authen	titate	▽ ₫ ≹ ⊠ 🗈 40 ¢
Q	Al Section 1 and 1 House 1 House 1 House 1	
	dell-monitor-firmware-update-utility	
	Installing	
	Authenticke To Install this package, you need to authenticate. Anapolication at employed to perform this excluse Passent Passent Cancel Authenticate	Ho screenhot available
V.	Version dell'monitor/firmware-update-utility:2:0:0:24	
·	Tradia des 4.0.40 when installed Likense Unknown Updelas Unknown	
	Reviews No network connection Connect to the internet to see more reviews.	English v Most helpful first v
	Connect on the materies of a set more revenue. This app has not been reviewed yet This app has not been reviewed yet	
7		




2 Execute firmware update tool via Ubuntu desktop.



3 Initializing for device status.




4 The utility will load the firmware file automatically. Or, you can select your file manually by clicking _____ and navigating to the UPG firmware file.



5 Click **Update**. The utility will start updating the new firmware.

E 1 D 11		
File Path	Home/Documents/Dell/firmware/U2424H/	
Model No	U2424H	
Current Firmware	M3B101	
New Firmware	M3B102	
File Checksum	716B	
Updating		
Updating	6 minutes. Do not power off or disconnect cable while updating.	
Updating		

6 Once the updating process is completed, please follow the on-screen instructions to restart your monitor.





NOTE: Update takes up to 6 minutes. Do not power off or disconnect cable while updating.

NOTE: If you experience problems during or after update, refer to Troubleshooting.

Install via Command

- 1 Copy deb file (e.g. Dell_U2424H_FWUpdate_M3B102_Ubuntu.deb) to the desktop.
- **2** Open the terminal and input command.

sudo dpkg -i filename


(e.g. sudo dpkg -i ~/Desktop/ Dell_U2424H_FWUpdate_M3B102_Ubuntu.deb)

```
dr41@dr41-CleanEnv:-/Desktop$ sudo dpkg -i Dell_U2424H_FWUpdate_M3B102_Ubuntu.deb
(Reading database ... 205729 files and directories currently installed.)
Preparing to unpack Dell_U2424H_FWUpdate_M3B102_Ubuntu.deb ...
do something before file install
change /home/dr41/bocuments/Dell permission
Unpacking dell-monitor-firmware-update-utility (2.0.0.31) over (2.0.0.31) ...
do something after file remove
Setting up dell-monitor-firmware-update-utility (2.0.0.31) ...
do something after file install
Processing triggers for gnome-menus (3.36.0-1ubuntu1) ...
Processing triggers for desktop-file-utils (0.24-1ubuntu3) ...
Processing triggers for fontconfig (2.13.1-2ubuntu3) ...
dr41@dr41<CleanEnv:-/Desktop$ []</pre>
```


3 Execute firmware update tool via Ubuntu desktop.

0	o firmware							Filter results →
	ii Applications							
3								
	monitor-firmware- update-utility							
V								
		â	A	6	Þ	5	ø	P

4 Initializing for device status.




5 The utility will load the firmware file automatically. Or, you can select your file manually by clicking ... and navigating to the UPG firmware file.



6 Click **Update**. The utility will start updating the new firmware.

File Path	Home/Documents/Dell/firmware/U2424H/	
Model No	U2424H	
Current Firmware	M3B101	
New Firmware	M3B102	
File Checksum	716B	
Updating	5 minutes. Do not power off or disconnect cable while updating.	

7 Once the updating process is completed, please follow the on-screen instructions to restart your monitor.





NOTE: Update takes up to 6 minutes. Do not power off or disconnect cable while updating.

NOTE: If you experience problems during or after update, refer to Troubleshooting.

Uninstall

1 Open the terminal and input command.

sudo dpkg -P dell-monitor-firmware-update-utility



Troubleshooting

Errors	Possible Solutions					
File permission error	 Save the firmware file in another location. Check if the firmware file has read permission. Check if you have owner rights for the firmware file. Run the utility with administrator privileges. 					
Monitor not detected	Follow Firmware Update Pre-requisites to check if the power and USB cables are properly connected to your computer and reopen the Monitor Firmware Update Utility.					
Write protection error	Re-try updating with the following steps:					
Flash erase error	1 Close the Monitor Firmware Update Utility.					
Update error	 2 Turn off the monitor by pressing the power button. 3 Re-plug the power cord. 					
Monitor firmware checksum error	 4 Turn on the monitor. 5 Try updating again with the Monitor Firmware Update Utility. 					
USB device inactive after new firmware installation.	Re-try the updating steps from 1 to 4 as stated above.					
A warning message appears: "Firmware update was not completed. Please update the monitor firmware again."	Re-try updating the monitor's firmware. Do not turn off the ISP tool until the update is complete.					