





1




2






3









4




5




6








7







8





9




10










11






I



2



3



If you need further assistance, visit our [Help Center](#) or contact [Ubiquiti Support](#).

© 2015 Ubiquiti Networks, Inc. All rights reserved. Ubiquiti, the Ubiquiti logo, UniFi, and UniFi logo are trademarks of Ubiquiti Networks, Inc. All other trademarks are the property of their respective owners.