




1




2





3








4





Compatible with
 ● All other bullet camera models
 ○ G4 Bullet, G3 Bullet




5




6







7




8



9




10




11


11




12




13




14




15




16








1



2



If you need further assistance, visit our [Help Center](#) or contact [Ubiquiti Support](#).