




1




2




3





4



5



i



Dell Display Manager:
Dell.com/DDM



Dell.com/support/E2425H

