

Contents:

- BC10 Battery Charger
- 90W AC-DC Adapter
- US/EU Power Cables
- Mounting bracket with screws (2)
- Tie-Wrap (1)



Quick Installation Guide

Elo M50 4-Slot Battery Charger (BC10)

Revision A
P/N E766165

Elo Technical Support

Online self-help: www.elotouch.com/support

America

800-ELO-TOUCH
Tel +1 408 597 8000
elosales.na@elotouch.com

Europe (EMEA)

Tel +32 (0)16 70 45 00
emea.sales@elotouch.com

Asia Pacific


Tel +86 (21) 3329 1385
www.elotouch.com.cn

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.



No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo and the Elo logo are either trademarks or registered trademarks of Elo Touch Solutions, Inc..






Wall or Counter Mount



Battery Installation

- Slide Battery into Tray and push down (at contact end)



Battery Removal

- Push down on Battery Eject Lever.
- Pull Battery up and out of Charger Tray

