

Branch



Assembly Instructions

Tools Required:

















- Pencil
- Electric Drill
- 7mm Spanner *or adjustable spanner
- 5.0mm Drillbit *if fixing from below
- 2.5mm Drillbit *if fixing from above
- 16mm Holesaw *if routing the tablet cable through your mounting surface
- Socket Driver


Sheet Code: BP-IM-034_REV2
Release Date: 28/10/2019

Copyright 2016 Spotspot Ltd. (T/A Bouncepad) all rights reserved. Confidential, no part of this publication may be reproduced or transmitted in any form without the written permission of the copyright holder.




* Due to the modular nature of our product range you may receive additional fixings in the fixings kit







B3 Locate the Cover to the Branch.




B4 Join the Branch & Mount Plate in the orientation shown.




B5 Secure the Branch to the surface with the 4x countersunk screws.




B6 Adhere the Mount Cover onto the Mount Plate with the adhesive tabs.




B7 Go to step 1.




1 Locate and attach the Bouncepad Case to the Branch as shown.




2 Unlock & remove the Faceplate from the Bouncepad Case.




3 Install the Tablet Setup Kit. Each kit is specific per tablet device and Bouncepad Case.




4 Feed the tablet cable through the Bouncepad Case & Branch.



5 Place the tablet into the Case and connect to power.



6 Locate & lock the Faceplate onto the Bouncepad Case.



7 Installation is now complete.