



Contents

1x Power-over-Ethernet (POE) Module
1x VESA mount spacer
2x M3x8 flat-head screws
VESA mounting screws

Power Limitation Note

The Power-over-Ethernet (POE) Module does not provide enough power to support all I-Series system features. Some features are disabled when using the POE Module. See the user guide for a detailed list of available features when using this adaptor kit.

Quick Installation Guide

I-Series 4 Android All-In-One Power-over-Ethernet (POE) Module Kit

Revision A
P/N E988344

Elo Technical Support

Online self-help: www.elotouch.com/support

America

800-ELO-TOUCH
Tel +1 408 597 8000
elosales.na@elotouch.com

Europe (EMEA)

Tel +32 16 930 136
emea.sales@elotouch.com

Asia Pacific

Tel +86 (21) 3329 1385
EloAsia@elotouch.com


The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.


Elo and the Elo logo are either trademarks or registered trademarks of Elo Touch Solutions, Inc.




- 1 Remove left side cable security cover and unplug ethernet and power cable from the device before installing the Power-over-Ethernet (POE) Module. **DO NOT install or remove the module with either of these cables connected or the I-Series 4 will be damaged.** Damage caused by installation with the cable(s) attached is not covered under Elo warranty.




- 2 Remove screw, then lift off POE docking cover.




- 3 Plug Elo POE module into recess, ensuring connector on bottom of adaptor lines up with connector on back of the I-Series 4.



- 4 Secure Elo POE module to the I-Series 4 using the included M3x8 screws. The power and ethernet cables can now be reconnected to the system.



- 5 **Optional 100x100 VESA spacer mounting:** Place the spacer over the Elo POE module before adding VESA mounting bracket.



- 6 Attach wallmount or stand mounting brackets (not included) with screws long enough to pass through the POE module and into the threaded holes of the I-Series 4 VESA mount. Maximum screw depth is 5mm.

Elo includes two types of M4x12mm screws that work with standard 2.6mm thick VESA brackets. Other brackets may require different length screws.

