




Dell Premier Multi Device Wireless Keyboard and Mouse

KM7321W

Quick Start Guide




1




3




5




2




3




2




3



3




3




3


1




2



3




4




4


1



2




2



3



3



3



<https://www.dell.com/support/drivers>

