




| Controller key | Switch  | PC Input |
|----------------|---------|----------|
| X              | Y       | X        |
| A              | B       | A        |
| B              | A       | B        |
| Y              | X       | Y        |
| +              | +       | Start    |
| -              | -       | Back     |
| L-Stick        | L-Stick | L-Stick  |
| R-Stick        | R-Stick | R-Stick  |
| L              | L       | LB       |
| R              | R       | RB       |
| LZ             | LZ      | LT       |


| Controller key  | Switch     | PC Input |
|---|------------|----------|
| RZ  | RZ         | RT       |
| L3  | L3         | L3       |
| R3  | R3         | R3       |
|  | Turbo      | Turbo    |
|  | Screenshot | N/A      |
| Up  | Up         | Up       |
| Down  | Down       | Down     |
| Left  | Left       | Left     |
| Right   | Right      | Right    |
|  | Home       | Guide    |

## MUTA USER GUIDE CONTROLLER

Bedienungsanleitung | Mode d'emploi | Gebruikershandleiding | Manuale utente | Manual del usuario | Guia do utilizador | Brukerveiledning | Bruksanvisning | Käyttöopas | Brugsvejledning | Instrukcja obsługi | Návod k použití | Návod na používanie | Használati útmutató | Manual de utilizare | Ръководство за потребителя | Εγχειρίδιο χρήσης | Kullanıcı kılavuzu | Руководство пользователя | Uporabniški priročnik | Korisnički priručnik | Guia do usuário | Посібник користувача | مودختس مولا لي لى د




1.





USB-A



2



100%, 75%, 50%, OFF



3



1 Y/A/B/X

2 T

Y/A/B/X + T = TURBO