

# Tilt & Swivel Adjustment



Tighten the bolt with the Allen Key to make the tilt and swivel adjustment.

## **Cable Management Installation**



Organize cables with cable management clips along the pole.

### **Gas Spring Aluminum LCD Monitor Desk Mount**





Amer Mounts 1-800-262-9703 Fax:1-800-314-6805 Email:sales@amer.com

Technical support 1-888-998-9189 Email:support@amer.com













Installation

**INSTRUCTIONS** 

#### **WARNING STATEMENTS**

## Warning



Prior to the installation of this product, the installation instruction must be read and completely understood. Failure to do so may result in personal injury, property damage or voiding of factory warranty.



Do not install on a structure that is prone to vibration, movement or chance of impact. Reinforce the structure as required before installation. Don't use the product on particle board.



The desk clamp can support a maximum thickness of 9 cm. Confirm the desk edge before installation.





Pay attention to the weight capacity of the mount. Exceeding the limitation can result in function unworkable or even serious personal injury and property damage.



Never operate the mount if parts are missing or damaged. Contact your local service center for warranty service.


#### PRODUCT LINE GRAPH






Lift the spring arm along with the monitor and put it on the supporting part.

### **Gas Spring Tension Adjustment**




Use a hex wrench to adjust the height tension of the gas spring arm, to keep different weight of monitors still at any position.

### **Arm Installation**



Insert extension arms to the supporting part.

### **Monitor Installation**




Recessed surface installation: Put 4 spacers between faceplate and monitor. Install 4 screws through faceplate, spacers to monitor via mounting holes.

## **TOOLS REQUIRED NOT INCLUDED**




## **PARTS INCLUDED**



	(Particular of the Control of the Co		
	M4x12 (x12)	M4x30 (x12)	
В			
	12X5.8X16 (x12)	(x1)	

С	M6x25 (x6)	(xi	6)
D	S=3mm (x1)	S=4mm (x1)	S=5mm (x1)
E	(x1)		

## **Clamp Installation Steps**



## **Grommet Installation Steps**

