bouncepad


Swivel Desk/S60

Assembly Instructions

Follow these instructions for the successful assembly your Bouncepad Swivel Desk/S60.


Sheet Code: BP-OR-IM-022_REV2 Release Date: 24/07/2019

Copyright 2016 Spotspot Ltd. (T/A Bouncepad) all rights reserved. Con dential, no part of this publication may be reproduced or transmitted in any form without the written permission of the copyright holder.




#2


0 In the box




0 Tools Required



Con gure the angle of rotation - ensuring both arrows are pointing in the same direction before starting. Default angle con guration is 270°. Insert the limit screws for 90° or 180° rotation.




Attach your chosen mounting arm. Your mounting arm must forward lean in the same direction as the two arrows. Tighten by hand, ensuring full and correct engagement.





Using the template (see A4) mark and drill the mounting holes appropriate to your mounting surface and cable routing con guration.


#3




4 Use the above template to mark the drill holes - appropriate to your chosen xing method. 'A' if xing from above. 'B' if xing from below. Follow the corresponding steps (PTO) specied to each xing method.








A1 Fixing From Above:
Lift & hold the rubber screw covers.
Use caution to not scratch the parts.




Fixing From Above:
Secure the base with the 4x screws.
Close the screw covers once nished.

A2

#6




Fixing From Below:
Screw in the 4x Socket Set Screws.
Ensure full thread engagment.




Metal Washer
Wing Nut

B2 Secure to the surface. Nylocs provide higher security whilst Wing Nuts allow for easier removal.



Installation of the mounting arm is complete. Now install your Case as shown above.



Install the Tablet Setup Kit. Each kit is speci c per tablet device and Bouncepad Case.





#8 Route your tablet cable through the Case. Install the tablet into the Case and connect to power.



#9 Locate and lock the Faceplate to the Case.