Yealink

Wireless Presentation Pod 无线传屏助手 WPP20



Quick Start Guide 快速入门指南 (V1

www.yealink.com

English|简体中文

Package Contents

If you find anything missing, contact your system administrator.







WPP20

Type-C Adapter

Quick Start Guide

Pairing WPP20 to Video Conferencing System

If you purchase video conferencing system and WPP20 together, they are already paired. Just connect the WPP20 to your computer for sharing content.

If the model of your video conferencing system is VC500/VC800, make sure a WF50 Wi-Fi USB dongle is connected to the system before you use the WPP20. If you purchase the WPP20 separately, you need to pair video conferencing system and WPP20 manually.

To pair video conferencing system and WPP20 manually:

 Connect the WPP20 to the USB port on the video conferencing system. Disconnect the WPP20 when the monitor prompts"Wi-Fi profile is already updated."

Starting or Stopping Sharing Content

To start or stop sharing content:

- Connect the WPP20/with type-C adapter connected to the USB/type-C port on your computer.
 Your WPP20 is paired with your video conferencing system automatically. And your computer starts the Yealink Wireless Presentation Pod software automatically.
- 2. Do one of the following to start sharing content:
 - On the WPP20, press the presentation button to share full screen.
 - On the WPP20, long press the presentation button for 3 seconds and then release this button.
 Choose the file you want to share and then click Share
 - Choose the file you want to share and then click **Share Now**.

 On the Yealink Wireless Presentation Pod software, click
 - Content Share.

 Choose the file you want to share and then click Share Now
- 3. Do one of the following to stop sharing content:
 - On the WPP20, press the presentation button.
 - On the Yealink Wireless Presentation Pod software, click Stop Sharing.

About Yealink

Yealink (Stock Code: 300628) is a global leading unified communication (UC) terminal solution provider that primarily offers video conferencing systems and voice communication solutions. Founded in 2001, Yealink leverages its independent research and development and innovation to pursue its core mission: "Easy collaboration, high productivity." The company's high-quality UC terminal solutions enhance the work efficiency and competitive advantages of its customers in over 100 countries. Yealink is the world's second-largest SIP phone provider and is number one in the China market.

Technical Support

Visit Yealink WIKI (http://support.yealink.com/) for the latest firmware, guides, FAQ, Product documents, and more. For better service, we sincerely recommend you to use Yealink Ticketing system (https://ticket.yealink.com) to submit all your technical issues.

YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD.
Web: www.yealink.com
Addr: 309, 3th Floor, No.16, Yun Ding North Road,
Huli District, Xiamen City, Fujian, P.R. China
Copyright@2019 YEALINK(XIAMEN) NETWORK
TECHNOLOGY CO.,LTD.All rights reserved.

包装清单

如果发现遗失任何配件,请联系你的系统管理员。



配对无线传屏助手和会议电视终端

如果你购买的是无线传屏助手和会议电视终端组合,二者默认自动配对,将无线传屏助手直接连在电脑上即可用于演示。如果会议电视终端为VC800/VC500,在使用前,你还需要在终端上接入USB无线网络适配器WF50。

如果你单独购买了无线传屏助手,你需要手动配对无线传屏助 手和会议电视终端。以实现一者的自动连接。

配对无线传屏助手和会议电视终端:

- 1. 将无线传屏助手插到会议电视终端的USB口上。
- 当显示设备提示"无线传屏器配对成功"时拔下无线传屏助

开始或结束演示

开始或结束演示:

- 1. 将无线传屏助手/已接type-C转接头的无线传屏助手插到电脑的USB/type-C接口上。
 - 无线传屏助手与会议电视终端自动连接,电脑自动开启亿联 无线传屏器软件。
- 2. 执行以下任一步骤开始演示:
 - 按无线传屏助手上的演示键,共享整个电脑屏幕。
 - 长按无线传屏助手上的演示键3秒后放开。
 选择要演示的文件,点击开始共享。
 - 在亿联无线传屏器软件上,点击内容分享。选择要演示的文件,点击开始共享。
- 3. 执行以下任一步骤结束演示:
 - 按无线传屏助手上的演示键。
 - 在亿联无线传屏器软件上,点击停止共享。

Regulatory Notices

Operating Ambient Temperatures

Operating temperature: +32 to 104°F (0 to 40°C)

- Blustive humidity: 5% to 90%, nencondensing

- Storage temperature: -22 to +160°F (-30 to +10°)

Warranty

Explanation of the symbols

WEEE Warning symbol

WEŁE Watring symbol

To avoid the potential effects on the environment and human health

as a result of the presence of hazardous substances in electrical and
electronic equipment, and users of electrical and electronic
quipment should understand the meaning of the crossed-out whoeled bir uipment should understand the meaning of the crossed-out wheeled bi ribol. Do not dispose of WEEE as unsorted municipal waste and have to lect such WEEE separately.

Restriction of Hazardous Substances Directive (RoHS)
This device complies with the requirements of the EU RoHS Directive.
Statements of compliance can be obtained by contacting support/lifyealink.co

Safety Instructions itery instructions ve these instructions. Read these safety instructions before use

A General Requirements

General incigurements. Before you install and use the divice, read the safety instructions carefully and closures the situation during operation, reading and several properties of the safety of the safety of the safety skep the device of year diction, and collisions and crash.

Places at attempt not to dimensite the divice by yourself, in case of any discrepancy places contact the appointed maintenance center for repair discrepancy places contact the appointed maintenance center for repair and places of the safety of the safety

▲ Environmental Requirements

Environmental Requirements

**Nace the dovice at a well-verifiated place. Do not expose the device under deed surfage.

**Keep the device of yard free of duels.

**Do not place the device on or near any influenceable or fre-vulnerable object, such as rubber—made materials.

**Keep the device away from any heat source or bare fire, such as a candle or an electric halor.

A Operating Requirements

Do not let a child operate the device without guidance.
 Do not let a child play with the device or any accessory in case of

Do not let a child play with the device or any accessory in case or accidental swallowing.
 Please use the accessories provided or authorized by the manufacturer.

socket only.

Before plugging or unplugging any cable, make sure that your hands are

During a thursders on near a swimming pool.
 During a thursderstorm, stop using the device and discorrect if from the power supply. Unplug the power plug and the Asymmetric Digital Subscriber Line (ADS), busided pair (the radio frequency cable) to avoid

lightning strike

ed for a rather long time, disconnect it from the If the device is left orbused for a fairner long little, disconnect it from the
power supply and unplug the power plug.
 When there is smoke emitted from the device, or some abnormal noise
or smell, disconnect the device from the power supply, and unplug the

power plug immediately. Contact the specified maintenance center for re-Contact the specified militizerance censes on expen Do not insert any object into equipment slots that is not part of the

Cleaning Requirements

Bafore cleaning the device, disconnect it from the power supply.

Use a piece of soft, dry and anti-static cloth to clean the device.

Keep the power plag clean and dry.

Troubleshooting

The usage environment is out of operating temperature range. 1. Use in the operating temperature range.

vice complies with part 15 of the FCC Rules. Operation is subject to the

vice complies with Industry Canada's Scence-exempt RSSs. Operation in

subject to the following two conditions:

(1) the doller amy part count infrastructure and cutting interference that cause infrastructure and cutting interference that cause understood operation of the dollers. Am LISS 3-109 is a private appear to confortine and CORT industries Canada applicable to private appear to confortine and CORT industries Canada applicable conditions suitantics.

(1) Toppearlies and only one producte due travaillage, confortine and confortine and characteristics and confortine and confortine confortine and confortine and characteristics and confortine and confortine and confortine and confortine and confortine and characteristics and confortine and

Radiation Exposure Statement REGISHOR EXPOSURE STATEMENT. This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Contlact Information

FEARING NETWORK TECHNOLOGY CO., LTD.

200, "3 of Doo, No. 16, "time Dreig Morth Road, Hall Distated, Xiarreen City, Eujian, P.R. Chit

FEARING (SUDDON) NA TWORK TECHNOLOGY GV.

FEARING (SUDDON) NA TWORK TECHNOLOGY GV.

FEARING (SIAR) NETWORK TECHNOLOGY CO., LTD.

**PRAING (SI

About Yealink

Yealink (Stock Code: 300628) is a global leading unified communication (UC) terminal solution provider that primarily offers video conferencing systems and voice communication solutions. Founded in 2001, Yealink leverages its independent research and development and innovation to pursue its core mission: "Easy collaboration, high productivity." The company's high-quality UC terminal solutions enhance the work efficiency and competitive advantages of its customers in over 100 countries. Yealink is the world's second-largest SIP phone provider and is number one in the China market.

Technical Support

Visit Yealink WIKI (http://support.yealink.com/) for the latest firmware, guides, FAQ, Product documents, and more. For better service, we sincerely recommend you to use Yealink Ticketing system (https://ticket.yealink.com) to submit all your technical issues.





YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD. Web: www.yealink.com

Addr: 309, 3th Floor, No.16, Yun Ding North Road, Huli District, Xiamen City, Fujian, P.R. China Copyright@2019 YEALINK(XIAMEN) NETWORK TECHNOLOGY CO., LTD. All rights reserved.