



Manual
Gebruiksaanwijzing
Gebruiksaanweisung
Mode d'emploi
Manual
Bruksanvisning
Brugsvejledning
Käyttöopas
Uživatelská příručka
Použivatelská příručka
Εγχειρίδιο χρήσης
مذخست س م ل ل د

XR103




#MOREENERGY

XTREME SERIES - Power your adventures

1




- 5000mAh Li-Polymer
- 139x79x14mm
- 167g
- Output: 1x USB-C 5V/2.1A
1x USB-A 5V/2.1A
- Input: USB-C Power Delivery 18W (5V/3A, 9V/2A, 12V/1.5A)
- Total output: 20W
- USB to USB-C cable, carabiner and manual



CARABINER

SUNPOWER®
SOLAR PANEL

POWER
BUTTON



POWERFUL
FLASHLIGHT

RUGGED
TEXTURE

IMPACT RESISTANT
BUMPERS

1X USB + 1XUSB-C
OUTPUTS


2



3




4




5



6




Best
illumination angle



Best time
of the day



Do not leave
out in the rain



The solar panel
doesn't work
behind a window



IMPORTANT

When charging for the first time we recommend that you charge the Solar Charger by USB with the included cable.

Also, when the internal battery of the Solar Charger is completely empty, you may have to charge it by USB power for a few minutes. Sometimes the charger needs a small energy boost before being able to generate solar power into energy.

7



LED POWER
INDICATORS

POWER
BUTTON

FLASHLIGHT 40LM

CHARGING INDICATION:
Press button 1x

FLASHLIGHT ON/OFF:
Press button 2x

LIGHT ON LIGHT OFF



POWER 75-100%

POWER 50-75%

POWER 25-50%

POWER 0-25%

1 2 3 4



20.000mAh

15.000mAh

10.000mAh

5000mAh

2500mAh

XTREME SERIES - Power your adventures

