


Anti-Static Mat

Product IDs

SM-ANTI-STATIC-MAT - 11.8 in x 18 in (30 cm x 46 cm) M3013 23.6 in x 27.5 in - (60 cm x 70 cm) LG-ANTI-STATIC-MAT - 23.6 in x 47.2 in (60 cm x 120 cm)

Product Diagram



Component		Function
1	Anti-Static Mat	Prevent ESD damage to sensitive hardware that is placed on top of the Anti-Static Mat .
2	Grounding Point	Grounding Wire connection point.
3	Grounding Wire With Alligator Clip	Connects to the designated Common Grounding Point of the work area.
		Warnings!
		Not meant to be used with a Wrist Strap .
		Not meant to be connected to another Anti-Static Mat .
		There should be only one Grounding Point to the Anti-Static Mat .

Package Contents

- Anti-Static Mat x 1
- · Grounding Wire With Alligator Clip x 1
- Quick-Start Guide x 1

Requirements

For the latest manuals, product information, technical specic cations, and declarations of conformance, please visit the corresponding product link:

www.startech.com/SM-ANTI-STATIC-MAT

www.startech.com/M3013

www.startech.com/LG-ANTI-STATIC-MAT

· Clean, dry, and at surface

Installation

- 1. Unroll the **Anti-Static Mat** in the work area. Allow the **Anti-Static Mat** to completely atten out at room temperature.
- 2. Determine where the **Common Grounding Point** is located in the work area. Ensure the **Common Grounding Point** is bare metal and free of paint or any other insulating material.
- 3. Connect the **Grounding Wire With Alligator Clip** to the **Grounding Point**, located on the corner on the **Anti-Static Mat**.
- 4. Clip the **Grounding Wire with Alligator Clip** onto the designated **Common Grounding Point**.

Regulatory Compliance

$Use \ of \ Trademarks, Registered \ Trademarks, and \ other \ Protected \ Names \ and \ Symbols$

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

Warranty Information

This product is backed by a two-year warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their o cers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of prots, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Safety Measures

· Read the entire manual and ensure the instructions are fully understood before assembling and/or using this product.

Mesures de sécurité

· Assemblez ce produit conformément aux instructions.

安全対策

必ず取扱説明書に従って本製品の組み立てを行って下さい。

Misure di sicurezza

· Assicurarsi di Assemblare il prodotto secondo le istruzioni.

Säkerhetsåtgärder

· Se till att du monterar produkten i enlighet med instruktionerna.

StarTech.com Ltd. 45 Artisans Crescent London, Ontario

N5V 5E9

Canada

StarTech.com LLP 4490 South Hamilton Road Groveport, Ohio 43125 U.S.A.

StarTech.com Ltd. Unit B, Pinnacle 15 Gowerton Road

Unit B, Pinnacle 1 Gowerton Road Brackmills, Northampton NN4 7BW United Kingdom

StarTech.com Ltd. Siriusdreef 17-27 2132 WT Hoofddorp The Netherlands

FR: startech.com/fr DE: startech.com/de ES: startech.com/es NL: startech.com/nl IT: startech.com/jp