



Picture: CHERRY STREAM KEYBOARD (JK-8500GB-2) with WetEx®-protective film

*Models may vary from the image shown*

## Flexible protective film for keyboards.

If it happens more roughly.

WetEx® protects keyboards from liquid spills, dust and dirt.

## Key benefits

- Resistant to distilled water, diesel, dishwashing liquid and isopropyl alcohol
- Conditionally resistant to petrol, oil and 40% sulphuric acid (battery acid)
- WET Ex® is free of halogens, latex and does not contain polybrominated diphenyl ethers
- Under normal conditions WET Ex® provides more than 10 million operating cycles
- Disposal does not produce polybrominated dibenzodioxin or dibenzofuran

## Technical Data

- Modulus of elasticity: 1200 PSI
- Spec. weight: 1.13 g/cm<sup>3</sup>
- Hardness: 84 IRHD
- Abrasion resistance: 6
- Elongation: 450%
- Tearing strength: 9000 PS

- Thickness: 0.25 mm
- Usage temperature: -40 °C to +70 °C
- Tensile strength: 400 lbs/inch

## Cleaning the protective film

You can disinfect the protective film with conventional disinfectants as specified by the manufacturer.

The resistance of the protective film was tested with the following disinfectants and a 5-minute exposure time:

- Isopropyl alcohol 70%
- Dentavon liquid
- Incidin liquid
- Kohrsolin FF
- Sterillium
- Desomed Rapid AF
- Dismozon

Use disinfectant according to the instructions and do not leave isopropyl alcohol 70% or dentavon liquid to act for too long.

**Packaging Unit:**

- **Number of products in the master package: 10**

**Keyboard layout features:**

- Product dependant, see table

**Keyboard family:**

- Product dependant, see table

Errors, technical changes and delivery possibilities excepted.  
Technical information refers only to the specifications of the  
products. Features may differ from the information provided.

## Warranty

We put a lot of dedication and hard work into the development of our products and we are proud of their quality. This is why, in addition to the statutory guarantee mentioned in the operating instructions, we are granting an expanded manufacturer's guarantee that is subject to the conditions stated below.

For the first two years after delivery, the statutory warranty applies. In the third year after delivery, CHERRY voluntarily grants an additional warranty according to the following conditions ("extended warranty"). In the event of a defect, please contact the seller of your CHERRY product. Do not carry out any repairs on your own and do not open the product. There is no warranty if unauthorized changes to the product cause a defect.

### Conditions for the extended warranty

In the case of a defect after the first 2 years after delivery of the CHERRY product, CHERRY grants its customers for the additional period of one year the right to assert claims for cure, i.e. demand that the defect is remedied or a thing free of defects is supplied. The extended warranty is to be asserted against the seller of the CHERRY product upon presentation of the original invoice, proof of purchase or a comparable proof of the time of purchase.

CHERRY, and the seller of the CHERRY product, where applicable, shall remedy the defect in the event the customer has justified claims for cure under the terms of the extended warranty.

Excluded from the extended warranty are damages caused by improper use, in particular by the effects of chemical substances, other damages caused by external influences, as well as normal wear and tear and optical changes, in particular discoloration or abrasion of shiny areas. Also excluded from the extended warranty are accessories and other parts which are not an integral part of the purchased item.

## European Keyboard Layout



BE (Belgium), CH (Switzerland), DE (Germany), DK (Denmark),  
 ES (Spain), FR (France), GB (UK English), GR (Greece),  
 IT (Italy), NL (Netherlands), NO (Norway), PL (Poland),  
 PN (Pan Nordic), PO (Portugal), RD (German / Cyrillic),  
 SF (Sweden / Finland), CS (Czech Republic, Slovenia)

Product Name	Product Number	Order-No.	EAN-Nr.	Features
<b>PC/SC Smartcard Keyboard</b>				
CHERRY KC 1000 SC	JK-A0100xx-	615-10004	4025112090370	
CHERRY KC 1000 SC-Z	JK-A0100xx-.-Z-			
CHERRY SECURE BOARD 1.0	JK-A0400xx-			
eHealth-BCS Tastatur	G87-1504...xx-	615-5211	4025112078132	
eGK-Tastatur	G87-1505...xx-			
<b>Compact Keyboard</b>				
Compact Keyboard	G84-41..Axx-	615-5044	4025112056635	Without Windows keys
Compact Keyboard	G84-41..Mxx-	615-5118	4025112056628	
Trackball Keyboard	G84-4400...xx- G84-4420...xx-	615-5140	4025112056642	Trackball cut out in foil
Keypad	G84-47...xx-	615-5173	4025112076268	
TouchBoard	G80-11900...xx-	615-5141	4025112023705	
Compact Keyboard	G80-18...xx- G81-18...xx-	615-5113	4025112058127	
XS Compact Keyboard	G84-5200...xx-	615-5199	4025112073243	
XS Trackball Keyboard	G84-5400...xx-	615-5201	4025112073267	
XS Touchpad Keyboard	G84-5500...xx-	615-5203	4025112073281	
CHERRY KC 4000	JK-0700xx	615-5218	4025112082672	
CHERRY KC 4020	JK-0720xx			
<b>Keyboard and Desktop-Sets</b>				
CHERRY KC 1000	JK-0800xx-	615-5217	4025112082306	
CHERRY KW 2000	JK-1700xx-			
CHERRY DC 2000 (Keyboard only)	JD-0800xx-			
CHERRY DW 3000 (Keyboard only)	JD-0700xx-			
STREAM	G85-23...xx-	615-5216	4025112082290	
STREAM XT				
STREAM XT T2				
STREAM 3.0				
STREAM 3.0 T2				
STREAM KEYBOARD	JK-8500xx-	615-10006	4025112094064	
STREAM KEYBOARD WIRELESS	JK-8550xx-			
STREAM KEYBOARD TKL	JK-8600xx-	615-10011	4025112099007	
STREAM DESKTOP	JD-8500xx-	615-10006	4025112094064	
STREAM DESKTOP RECHARGE	JD-8560xx-			
Standard Keyboard	G80-30...xx- G81-30...xx-	615-5080	4025112056611	
Standard Keyboard	G83-6105...xx- G83-6188...xx- G83-6260...xx- G83-6236...xx- G83-6919...xx-	615-5139	4025112023699	

xx = Country code

\* The keyboard number is located on the type label on the underside of the keyboard (marked as P/N)

International Keyboard Layout



**US** (US-English), **EU** (US English / international with €),  
**BB** (Bulgaria), **IL** (US English / Hebrew),  
**RB** (US English / Cyrillic), **RL** (US English / Cyrillic / Lithuanian)

Product Name	Product Number*	Order-No.	EAN-Nr.	Features
<b>PC/SC Smartcard Keyboard</b>				
CHERRY KC 1000 SC	JK-A0100 <b>xx</b> -.	615-10009	4025112095009	
CHERRY KC 1000 SC-Z	JK-A0100 <b>xx</b> -.Z-			
CHERRY SECURE BOARD 1.0	JK-A0400 <b>xx</b> -.			
<b>Compact Keyboard</b>				
Compact Keyboard	G84-41...A <b>xx</b> -.	615-5044	4025112056635	Without Windows keys
Compact Keyboard	G84-41...M <b>xx</b> -.	615-5118	4025112056628	
Trackball Keyboard	G84-4400... <b>xx</b> -. G84-4420... <b>xx</b> -.	615-5147	4025112058158	Trackball cut out in foil
Keypad	G84-47... <b>xx</b> -.	615-5173	4025112076268	
TouchBoard	G80-11900... <b>xx</b> -.	615-5142	4025112023712	
Compact Keyboard	G80-18... <b>xx</b> -. G81-18... <b>xx</b> -.	615-5112	4025112058110	
XS Compact Keyboard	G84-5200... <b>xx</b> -.	615-5200	4025112073250	
XS Touchpad Keyboard	G84-5500... <b>xx</b> -.	615-5204	4025112073298	
<b>Keyboard and Desktop-Sets</b>				
STREAM KEYBOARD	JK-8500 <b>xx</b> -.	615-10007	4025112094071	
STREAM KEYBOARD WIRELESS	JK-8550 <b>xx</b> -.			
STREAM KEYBOARD TKL	JK-8600 <b>xx</b> -.	615-10010	4025112098994	
STREAM DESKTOP	JD-8500 <b>xx</b> -.	615-10007	4025112094071	
STREAM DESKTOP RECHARGE	JD-8560 <b>xx</b> -.			
Standard Keyboard	G80-30... <b>xx</b> -. G81-30... <b>xx</b> -.	615-5079	4025112056604	
Standard Keyboard	G83-6105... <b>xx</b> -. G83-6188... <b>xx</b> -. G83-6260... <b>xx</b> -. G83-6236... <b>xx</b> -.	615-5138	4025112023729	

**xx** = Country code

\* The keyboard number is located on the type label on the underside of the keyboard (marked as P/N)