



OXes brai



Quick Start Guide

for Brainboxes Ethernet Switch Range









Thank you for choosing this Brainboxes product

This quick start guide will help you set up your SW device so that you can quickly and easily begin experiencing the benefits of your Brainboxes Ethernet Switch.







Quick Start Guide





- Suitable for use with SW-005, enables clip on DIN rail mounting



PW-650 USB - Suitable for use with all SW-5XX products


For more information, please refer to the datasheet

Information on Product Accreditations, Safety, and correct disposal of this product can be found on our website www.brainboxes.com

Hardware Specifications: SW-005



Hardware Specifications: SW-5XX




Connecting device

All SW devices can be connected to any power supply providing at least 1.1 Watts of power at +5VDC to +30VDC. Alternatively PW-600 and PW-650 are optional power supplies that enable the device to be plugged into a standard power socket or powered via USB.

SW-005:

The three pin power terminal block is removable. Power LED will light green when correctly connected.



PIN	FUNCTION
1	+V Power
2	-V Power
3	Functional Earth

SW-5XX:

The black numbered power terminal block is removable. Two separate sets of power supply inputs terminals are provided, one to +VA and -V and the other to +VB and -V. This provides redundancy; the second power supply automatically takes over in the event of a failure of the first one. If only one power supply is connected then the negative must be connected to one of the -V pairs. The positive can be connected to either the +VA or +VB pins. Power LED will light green when correctly connected.

PIN	FUNCTION	
1	-V	
2	+VA	
3	+VB	
4	-V	
5	Functional Earth	

Mag Jack LEDs

All Ethernet ports are Auto MDIX and so straight through or crossover Ethernet cables can be used to connect to your Ethernet devices.

Link/Activity LED	Solid green	Connection established
	Flashing Green	Data communication
Speed LED (SW-005	Green	100Base-Tx
& SW-504)	Unlit	10Base-T

Contact Us

Brainboxes Limited

Tel: +44 (0)151 220 2500

18 Hurricane Drive,

Liverpool International Business Fax: +44 (0)151 252 0446

Park,

Speke, Email: sales@brainboxes.com

Liverpool Merseyside L24 8RL,

United Kingdom Web: www.brainboxes.com

Brainboxes LLC

Tel: +1 (855) 958 2502

4500 140th Avenue

North Toll Free Fax: +1 (888) 958 5538

Suite 101, Clearwater

FL 33762, USA

Brainboxes Japan

Tel: +81-3-3683-0509

8-26-5-506

Kameido, Koto-ku, Fax: +81-3-3683-0509

Tokyo, Japan

