


## AXIS T94P01L Recessed Mount

## Installation Guide




AXIS T94P01L Recessed Mount


---



**1x**



**1x**




AXIS M5525-E






**4x**


# AXIS T94P01L Recessed Mount




If you install the product in an air handling system, you must use a metal conduit for the RJ45 cable to make it fire-proof.




# 1.1




# 1.2




# 1.3



# 1.4



# 1.5



# 1.6

