



# XTRFY M4 QUICK START GUIDE



## CPI


- 400
- 800
- 1200
- 1600
- 3200
- 4000
- 7200
- 16000




POLLING RATE




125 Hz 500Hz 1000Hz







+




BRIGHTNESS





+







+



 FOR MORE INFORMATION, DOWNLOAD THE MANUAL AT [XTRFY.COM](http://XTRFY.COM)


 FÖR MER INFORMATION, LADDA NER DEN FULLSTÄNDIGA MANUALEN PÅ [XTRFY.COM](http://XTRFY.COM)

 FOR MER INFORMASJON LAST NED BRUKSANVISNINGEN PÅ [XTRFY.COM](http://XTRFY.COM)

 FOR MERE INFORMATION, DOWNLOAD VORES FULDE MANUAL PÅ [XTRFY.COM](http://XTRFY.COM)


 LISÄTIETOJA SAAT LATAAMALLA KOKO KÄYTTÖOHJEEN [XTRFY.COM](http://XTRFY.COM)-VERKKOSIVUSTOLLA.


 FÜR WEITERE INFORMATIONEN, LADEN SIE DAS VOLLSTÄNDIGE HANDBUCH BEI [XTRFY.COM](http://XTRFY.COM)

 POUR PLUS D'INFORMATIONS, TÉLÉCHARGEZ LE MANUEL COMPLET SUR [XTRFY.COM](http://XTRFY.COM)


 SI DESEAS OBTENER MÁS INFORMACIÓN, DESCARGA EL MANUAL COMPLETO DESDE [XTRFY.COM](http://XTRFY.COM)

 PARA MAIS INFORMAÇÕES, TRANSFIRA O MANUAL COMPLETO EM [XTRFY.COM](http://XTRFY.COM)

 PER ULTERIORI INFORMAZIONI, SCARICA IL MANUALE COMPLETO SU [XTRFY.COM](http://XTRFY.COM)


 DETAYLI BILGI İÇİN LUTFEN [XTRFY.COM](http://XTRFY.COM)'DAN KULLANIM KILAVUZUNU İNDİRİN.


 WŁI CEJ INFORMACJI ZNAJdziesz W INSTRUKCJI OBSŁUGI, DOST PNEJ NA [XTRFY.COM](http://XTRFY.COM)


 PRO VÍCE INFORMACÍ SI STAHNĚTE KOMPLETNÍ MANUÁL NA [XTRFY.COM](http://XTRFY.COM)



[XTRFY.COM](http://XTRFY.COM)

 자세한 정보는 [XTRFY.COM](http://XTRFY.COM)에서 전체 매뉴얼을 다운로드하거나.

 想要得到更多信息, 请在[WWW.XTRFY.COM](http://WWW.XTRFY.COM)网站上下载说明书.

 設定や他の情報の詳細は、[xtrfy.jp](http://xtrfy.jp)から取扱説明書をダウンロードしてください。

