




ELV8

USER MANUAL

1

A



x1

B



x3

C



x1

D





x1

E






x1

2



3





Asia Pacific - Cooler Master Technology Inc.
8F., No. 788-1, Zhongzheng Rd., Zhonghe Dist.,
New Taipei City 23586, Taiwan (R.O.C.).
Tel: +886-2-2225-3517

China - Cooler Master China
Room 2062, Floor 6, No. 421, Weiqing Rd.,
Jinshan District, Shanghai City, China
Tel: +86-21-51872177

Europe - Cooler Master Europe B.V.
Lodewijkstraat 1b, 5652AC Eindhoven, The Netherlands
Tel: +31-(0)40-702-0900

North America - Cooler Master NA
2929 E. Imperial Hwy STE 110, Brea, CA 92821, USA
Tel: +1-888-624-5099

For the most updated information, please visit our official
website: www.coolermaster.com/
Cooler Master Support: <https://account.coolermaster.com/>



512002660-GP Ver 1.0: 2019/06

©2019 Cooler Master Technology Inc. All Rights Reserved.
All trademarks are registered to their respective owners.