


# INSTALLATION GUIDE

## AXIS T94F01P Conduit Box




1x



1x





4x




1


i




2




3




4







5




6




7




8




9



10



11



**AXIS**  
COMMUNICATIONS





Installation Guide

AXIS T94F01P Conduit Box

© Axis Communications AB, 2013

Ver.1.0

Printed: November 2013

Part No. 52188