

# We love that you are rocking JLab! We take pride in our products and fully stand behind them.



#### YOUR WARRANTY

All warranty claims are subject to JLab authorization and at our sole discretion. Retain your proof of purchase to ensure warranty coverage.



#### **CONTACT US**

Reach out to us at support@jlab.com
or visit jlab.com/contact

#### **REGISTER TODAY**

jlab.com/register


Product updates | How-to tips

FAQs & more

### 1) CONNECT WITH DONGLE

# Install 2.4G USB dongle and switch keyboard on

Epic Keys will auto connect





If connection is unsuccessful, press and hold 2.4 until button flashes quickly. Unplug and re-plug dongle into computer.


# **2** CONNECT WITH BLUETOOTH

Press and hold \$1 or \$2 for Bluetooth pairing LED will blink in pairing mode

#### **Press and hold CONNECT**


Select "JLab Epic Keys" in device settings





### **SHORTCUT KEYS**

Fn +	MAC	PC	Android
Esc	FN Lock	FN Lock	FN Lock
F1	Brightness -	Brightness -	Brightness -
F2	Brightness +	Brightness +	Brightness +
F3	Task Control	Task Control	N/A
F4	Show Applications	Notification Center	N/A
F5	Search	Search	Search
F6	Backlit -	Backlit -	Backlit -
F7	Backlit +	Backlit +	Backlit +
F8	Track Back	Track Back	Track Back
F9	Track Forward	Track Forward	Track Forward
F10	Mute	Mute	Mute
F11	Screenshot	Screenshot	N/A
F12	N/A	Calculator	N/A



Customize the Epic Keys with USB dongle + JLab Work App jlab.com/software



#### Shop products | Product alerts | Burn-in your headphones

JLab Store + Burn-in Tool



