

www.datavideo.com

## **Table of Contents**

FCC COMPI	IANCE STATEMENT	3			
WARNINGS	AND PRECAUTIONS	3			
WARRANT	(	4			
Standari Three Yez DISPOSAL .	) WARRANTY AR WARRANTY				
CHAPTER 1	PRODUCT OVERVIEW	6			
1.1	Features	6			
1.2	FORMATS CONVERSION TABLE	6			
CHAPTER 2	CONNECTIONS AND CONTRO	LS7			
2.1	FRONT PANEL	7			
2.2	REAR PANEL				
CHAPTER 3	DAC CENTER				
INFORMAT	TION				
VIDEO					
AUDIO					
Proc Am	Ргос Амр 15				
SETTING	Setting				
FIRMWARE	UPDATE				
FREQUENT	LY-ASKED QUESTIONS				
DIMENSIO	NS				
SPECIFICAT	IONS				
SERVICE AN	ID SUPPORT				

#### **Disclaimer of Product & Services**

The information offered in this instruction manual is intended as a guide only. At all times, Datavideo Technologies will try to give correct, complete and suitable information. However, Datavideo Technologies cannot exclude that some information in this manual, from time to time, may not be correct or may be incomplete. This manual may contain typing errors, omissions or incorrect information. Datavideo Technologies always recommend that you double check the information in this document for accuracy before making any purchase decision or using the product. Datavideo Technologies is not responsible for any omissions or errors, or for any subsequent loss or damage caused by using the information contained within this manual. Further advice on the content of this manual or on the product can be obtained by contacting your local Datavideo Office or dealer.

## **FCC Compliance Statement**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

## Warnings and Precautions

- 1. Read all of these warnings and save them for later reference.
- 2. Follow all warnings and instructions marked on this unit.
- 3. Unplug this unit from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- 4. Do not use this unit in or near water.
- 5. Do not place this unit on an unstable cart, stand, or table. The unit may fall, causing serious damage.
- 6. Slots and openings on the cabinet top, back, and bottom are provided for ventilation. To ensure safe and reliable operation of this unit, and to protect it from overheating, do not block or cover these openings. Do not place this unit on a bed, sofa, rug, or similar surface, as the ventilation openings on the bottom of the cabinet will be blocked. This unit should never be placed near or over a heat register or radiator. This unit should not be placed in a built-in installation unless proper ventilation is provided.
- This product should only be operated from the type of power source indicated on the marking label of the AC adapter. If you are not sure of the type of power available, consult your Datavideo dealer or your local power company.
- 8. Do not allow anything to rest on the power cord. Do not locate this unit where the power cord will be walked on, rolled over, or otherwise stressed.
- 9. If an extension cord must be used with this unit, make sure that the total of the ampere ratings on the products plugged into the extension cord do not exceed the extension cord rating.
- 10. Make sure that the total amperes of all the units that are plugged into a single wall outlet do not exceed 15 amperes.
- 11. Never push objects of any kind into this unit through the cabinet ventilation slots, as they may touch dangerous voltage points or short out parts that could result in risk of fire or electric shock. Never spill liquid of any kind onto or into this unit.
- 12. Except as specifically explained elsewhere in this manual, do not attempt to service this product yourself. Opening or removing covers that are marked "Do Not Remove" may expose you to dangerous voltage points or other risks, and will void your warranty. Refer all service issues to qualified service personnel.
- 13. Unplug this product from the wall outlet and refer to qualified service personnel under the following conditions:
  - a. When the power cord is damaged or frayed;
  - b. When liquid has spilled into the unit;
  - c. When the product has been exposed to rain or water;
  - d. When the product does not operate normally under normal operating conditions. Adjust only those controls that are covered by the operating instructions in this manual; improper adjustment of other controls may result in damage to the unit and may often require extensive work by a qualified technician to restore the unit to normal operation;
  - e. When the product has been dropped or the cabinet has been damaged;
  - f. When the product exhibits a distinct change in performance, indicating a need for service.



### Warranty Standard Warranty

- Datavideo equipment are guaranteed against any manufacturing defects for one year from the date of purchase.
- The original purchase invoice or other documentary evidence should be supplied at the time of any request for repair under warranty.
- The product warranty period begins on the purchase date. If the purchase date is unknown, the
  product warranty period begins on the thirtieth day after shipment from a Datavideo office.
- All non-Datavideo manufactured products (product without Datavideo logo) have only one year warranty from the date of purchase.
- Damage caused by accident, misuse, unauthorized repairs, sand, grit or water is not covered under warranty.
- Viruses and malware infections on the computer systems are not covered under warranty.
- Any errors that are caused by unauthorized third-party software installations, which are not required by our computer systems, are not covered under warranty.
- All mail or transportation costs including insurance are at the expense of the owner.
- All other claims of any nature are not covered.
- All accessories including headphones, cables, and batteries are not covered under warranty.
- Warranty only valid in the country or region of purchase.
- Your statutory rights are not affected.

### **Three Year Warranty**

 All Datavideo products purchased after July 1st, 2017 are qualified for a free two years extension to the standard warranty, providing the product is registered with Datavideo within 30 days of purchase.



- Certain parts with limited lifetime expectancy such as LCD panels, DVD drives, Hard Drive, Solid State Drive, SD Card, USB Thumb Drive, Lighting, Camera module, PCIe Card are covered for 1 year.
- The three-year warranty must be registered on Datavideo's official website or with your local Datavideo office or one of its authorized distributors within 30 days of purchase.

### Disposal



#### For EU Customers only - WEEE Marking

This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is

recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.



**CE Marking** is the symbol as shown on the left of this page. The letters "**CE**" are the abbreviation of French phrase "Conformité Européene" which literally means "European Conformity". The term initially used was "EC Mark" and it was officially replaced by "CE Marking" in the Directive 93/68/EEC in 1993. "CE Marking" is now used in all EU official documents.

## Chapter 1 Product Overview

Datavideo DAC-45 4K up / down / cross converter is designed to convert video signals from VGA, HDMI, SDI with Audio input to 4K HDMI or 3G-SDI output. It allows instant and automatic switch between 4K, HD and SD video formats when the video input changes.

### 1.1 Features

- HDMI 2.0 input/output with 4:2:2 processing
- Up/Down/Cross convert between SD, HD, 3G and 4K formats
- SDI(3G)/HDMI(4K)/VGA Input
- SDI(3G)/HDMI(4K) Output
- Support 3G-SDI Level A/B
- Reference input (Black Burst and Tri-Level Sync.)
- Built-in Super Resolution Engine for 4K Up Conversion
- Built-in Resolution & Frame rate Up/Down Conversion Engine
- Built-in De-interlacer and Interlacer (I <-> P conversion )

### 1.2 Formats Conversion Table



## Chapter 2 Connections and Controls

### 2.1 Front Panel

datavideo 📭	-45 4K UP/ DOWN CROSS CONVERTER
	SOURCE OUTPUT MODE
	Power Switch Turns ON/OFF the device
OOOOOOOOOOOOOOOOOOOOOOOOOOOOOOOOOOOOOO	<ul> <li>Source LED Indicators</li> <li>Only one input can be enabled at a time. For details on how to select the source, see the DIP Switch descriptions in the <u>Rear Panel</u> section.</li> <li>ON (Red): Enabled but signal not detected</li> <li>ON (Green): Enabled with valid connection</li> <li>OFF: Disabled</li> </ul>
<ul> <li>○</li> <li>○</li></ul>	<b>Output Mode LED Indicators</b> Only one output mode can be enabled at a time. For details on how the output mode can be selected, see the DIP Switc descriptions in the <u>Rear Panel</u> section.

ON (Green): Enabled OFF: Disabled

### 2.2 Rear Panel



Video IN				
	VGA IN This port connects the VGA source device. Set the DIP SW 1/2 to 00 before connecting the VGA source device to this port.			
HDMI	HDMI IN This port connects the HDMI source device. Set the DIP SW 1/2 to 01 before connecting the HDMI source device to this port.			
SDI	SDI IN This port connects the SDI source device. Set the DIP SW 1/2 to 10 before connecting the SDI source device to this port.			
REF	<b>REF IN (Genlock)</b> The DAC-45 can be synchronized with the connected input device. <b>REF IN</b> will accept <b>Tri-level</b> and <b>Black Burst</b> sync. Set <b>DIP SW 3</b> to <b>1</b> to enable the Genlock feature. To disable this port, simply set <b>DIP SW 3</b> to <b>0</b> .			
	Video OUT			
НОМІ	HDMI OUT This port connects the HDMI destination device.			
SDI	SDI OUT This port connects the SDI destination device.			
Audio IN				
R	Audio Input – Stereo RCA (Left/Right) Connects unbalanced analog audio source (stereo) for audio embedding.			

Mode Select					
DIP Switch         The DIP Switch allows you to configure the device settings.         The table below provides details of the DIP Switch Settings.					
SOURCE sets the type of the input device connected.					
GENLOCK enables/disables the REF IN port.					
AUDIO allows you to determine the audio source. Note: No audio is heard after switching the VGA IN audio source to the HDMI audio source.					
	<b>4K</b> toggles between Full HD and 4K modes.				
	<b>VIDEO OUTPUT</b> sets the resolution and frame rate (the output mode). Please note the low nibble determines the resolution and frame rate of the output depending on the setting of the 4K bit.				
DIP SWITCH SETTING         DAC-45           SOURCE         GENLOCK         AUDIO           VGA         10 SDI         FREE           1 HDMI         11 PC         REF-IN					
	VIDEO OUTPUT				
0000 1920x1080p60 3840x2160p60	0100 <sup>1920x1080p29.97</sup> 3840x2160p29.97 1000 1920x1080/60 1100 1280x720p59.94				
0001 1920x1080p59.94 3840x2160p59.94	0101 1920x1080p25 3840x2160p25 1001 1920x1080159.94 1101 1280x720p50				
0010 1920x1080p50 3840x2160p50	0110 1920x1080p24 1010 1920x1080i50 1110 720x480i59.94				
0011 1920x1080p30 3840x2160p30	0111 1920x1080p23.98 3840x2160p23.98 1011 1280x720p60 1111 720x576i50				
Firmware Upgrade					
USB firmware upgrade port         Connects the DAC-45 device to the PC for firmware upgrade         See the Firmware Update         section for details.					
	DC IN				
DC IN Socket Connects the supplied 12V PSU to this socket. The connection can be secured by screwing the outer fastening ring of the DC In plug to the socket.					

## Chapter 3 DAC Center

DAC-45 Center Utility is a Graphical User Interface that allows the user to obtain the device information and perform various video and audio settings.

To use the utility, the user should first copy the *DAC-45 Center.exe* utility software from the installation CD to the computer running Windows. After that, connect the DAC-45 to the same computer using the USB cable. Switch on the DAC-45 and open the DAC-45 Center Utility software.

### Information

Click the **Information tab** to obtain the information on input format and firmware version.

DAC45	56	Up/Down/Cross Converter with Genlock	<b>data</b> video*
Information	_ Info	rmation	
Video	Ir	nput Format : - NO SIGNAL -	
Audio <	Ir	nput Color : RGB444	
Proc Amp	F	W Version : 0.1.0.5	
Setting			
		www.datavideo.com	
Refresh			

### Video

Click the Video tab to enter the video setup page.



On the video setup page, click the Video Setting button to enter the video configuration page.



#### Set the Input Source, HDMI Output Color and Output Format.

DAC	45	Jp/Down/Cross	datavideo*
Next Page	Control	Mode	
Apply	USE	3	
Return	Input So	burce	
	VGA	A	>>
	HDMIC	Output Color	
	RG	3444	>>
	Output	Format	
	192	0x1080 60.00p	<< >>
Refresh 🛛 <			

#### Input Source

- VGA
- HDMI •
- SDI •

#### **HDMI Output Color**

- YUV422 •
- YUV444
- **RGB444**

#### **Output Format**

- 720x480 59.94i •
- 720x576 50.00i •
- 4096x2160 60.00p •
- 4096x2160 59.94p •
- 4096x2160 50.00p
- 4096x2160 30.00p
- 4096x2160 29.00p •
- 4096x2160 25.00p
- 4096x2160 24.00p
- 4096x2160 23.98p
- 3840x2160 60.00p

- 3840x2160 59.94p
- 3840x2160 50.00p
- 3840x2160 30.00p
- 3840x2160 29.97p
- 3840x2160 25.00p
- 3840x2160 24.00p
- 3840x2160 23.98p
- 1920x1080 60.00p
- 1920x1080 50.00p
- 1920x1080 30.00p

- 1920x1080 29.97p •
- 1920x1080 25.00p •
- 1920x1080 24.00p
- 1920x1080 23.98p •
- 1920x1080 60.00i •
- 1920x1080 59.94i •
- 1920x1080 50.00i •
- 1280x720 60.00p
- 1280x720 59.94p
- 1280x720 50.00p

Click Apply after all settings are configured.

- 1920x1080 59.94p

**Note**: When **Control Mode** displays **USB**, it indicates that the device is accessible by the PC. When **Control Mode** displays **DipSwitch**, the device is only configurable by the DIP Switch.

Click Next Page to set the Super Resolution Mode, Aspect Ratio and 3G Level-B.

DAC4	45 Up/Down/Cross Converter with Genlock	datavideo*
Next Page	Super Resolution Mode	
Apply	High	>>
Return	Aspect Ratio	
	Keep Aspect Ratio	>>
	Enable 3G Level-B	
	Disable	>>
Refresh 🚽		

#### **Super Resolution Mode**

- Low
- Middle
- High
- Disable

#### Aspect Ratio

- Keep Aspect Ratio
- Full Screen (16:9)
- Dot By Dot
- 4:3
- 14:9
- UnderScan
- Pan Scan 16:9

#### Enable 3G Level-B

- Enable
- Disable

Click **Apply** after all settings are configured.

### Audio

Click the Audio tab to set audio parameters.



Set the Audio Mute, Audio Source and Audio Level.

Apply   Return     Audio Mute   OFF   Audio Source   Default   Audio Level   SMPTE(USA)	DAC4	5	Up/Down/Cross Converter with Genlock	datavideo*
	Apply Return	Audic Of Audic De Audic	o Mute FF o Source ofault o Level MPTE(USA)	>>

#### Audio Mute

- ON
- OFF

#### Audio Source

- Default
- SDI
- HDMI
- L/R Audio

Audio Level

- SMPTE(USA)
- EBU(Europe)

Note: Audio Level allows the user to select EBU or SMPTE standards.

Click Apply after setting the Audio Mute, Audio Source and Audio Level.

### **Proc Amp**

Click the Proc AMP tab to adjust the picture settings.



Set the Brightness, Contrast, Hue, and Saturation levels on the Proc Amp setup page.

DAC45	56	Up/Down Converte	n/Cross er with Gen	lock	(11)(11)	data	video°
Default	- Pro	Amn —					
Return	Br	ightness				128	
	Co	ontrast				128	
	Hu	е		_]		128	
	Sa	turation				128	

### Setting

To restore the factory default settings, click the Setting tab.



Click the Factory Default button to reset the DAC-45 to factory defaults.

DAC45		Up/Down/Cross Converter with Genlock	datavideo*
Apply	OSE	) Hide Mode	
Return	Di	sable	>>
	No S	signal Mode	
	BI	ack Screen	>>
		A Factory Default	

In addition, the user can also set **OSD Hide Mode** and **No Signal Mode**. Details of these two modes are described in the table below.

**OSD Hide Mode** When enabled, source information and output resolution will not be displayed on the screen upon resolution change.

**No Signal Mode** This sets how the screen looks like when there is no signal. The available options are listed below.

- Black Screen
- Blue Screen
- Disable Output

## **Firmware Update**

Datavideo usually releases new firmware containing new features or reported bug fixes from time to time. Customers can either download the DAC-45 firmware as they wish or contact their local dealer or reseller for assistance.

This section outlines the firmware upgrade process which should take *approximately 10 minutes to complete*.

The existing DAC-45 settings should persist through the *firmware upgrade process,* which should not be interrupted once started as this could result in a non-responsive unit.

#### Successful firmware upgrade on DAC-45 requires:

- 1. The latest firmware file for the DAC-45. This can be obtained from your local Datavideo dealer or office.
- 2. The Upload Firmware utility. This can also be obtained from your local Datavideo dealer or office.
- 3. A Windows PC with USB 2.0 port.
- 4. A USB A to micro USB cable (USB 2.0).

#### How to update the DAC-45 firmware

- 1. Switch off the DAC-45 power.
- 2. Save the latest firmware file and the Upload Firmware utility to the PC desktop.



DataVideo Upload Firmware.exe DataVideo Upload Firmware Datavideo Technologies Co., Ltd

- 3. Use USB 2.0 cable to connect the DAC-45 to the computer.
- 4. Open the Datavideo Upload Firmware utility, which will show **Disconnected** and the connect button is greyed out.
- 5. Switch on the DAC-45 power and the connect button will now be enabled. Click the connect button and the Utility will show **Connected.**
- 6. Click the Open File button and select the new firmware file.
- 7. Click the Start button and wait for the progress bar to finish.
- 8. After the update is finished, the utility will show **PASS** to confirm that the unit has been updated successfully.
- 9. The utility will automatically disconnect the DAC-45 unit.
- 10. Unplug the USB cable from the DAC-45 and power cycle the unit.
- 11. The updated DAC-45 is now ready for use.

## **Frequently-Asked Questions**

This section describes problems that you may encounter while using DAC-45. If you have any questions, please refer to related sections and follow all suggested solutions. If problem still exists, please contact your distributor or the service center.

No.	Problems	Solutions
1.	Must <b>Genlock IN</b> and <b>SDI IN / OUT</b> have the same frame rate in order to be in sync?	Genlock IN only needs to have the same frame rate with SDI OUT in order to be in sync. For example, SDI IN is at 1080p60, Genlock IN is at 1080p50 and SDI OUT is at 720p50.
2.	Are <b>SD</b> and <b>HD</b> cross referenceable? For example, Genlock IN is SD Black Burst and SDI OUT is HD tri-level <b>OR</b> Genlock IN is HD tri-level and SDI OUT is SD Black Burst.	SD and HD are cross referenceable.
3.	Image distortion occurs when using the DIP Switch to set resolution and frame rate.	This issue can be eliminated by rebooting the device.

## Dimensions



All measurements in millimeters (mm)

# Specifications

	Interfaces
Innuts	VGA x 1 , HDMI x 1 , HD/SD-SDI x 1
inputs	RCA x 2 (Unbalanced Audio L/R), Reference Input x 1
Outputs	SDI x 1, HDMI x 1
	Power LED x 1
Indicator	Source LED x 3 (VGA, HDMI, SDI)
E/M/ Undetee and	Output Format LED x 3 (4K, 3G, HD, SD)
F/W Opdates and	Mini USB x 1
DC IN	DC lack
	Standard
	SDI (YUV)
	1080p60/59.94/50, 1080p30/29.97/25/24/23.98
	1080nsf30/29 97/25/24/23 98
	1000p3/50/20.23/22/22/23/50
	1080100/39.94/30, 720p00/39.94/30
	5251, 6251
	HDMI (YUV / RGB)
	3840x2160p60/59.94/50
	3840x2160p30/29.97/25/24/23.98
Supported Video	1080p60/59.94/50.1080p30/29.97/25/24/23.98
Input Format	1080psf30/29 97/25/24/23 98
•	1000p3/50/E0 04/E0 720p50/E0 04/E0
	800x600@60Hz, 1024x768@60Hz, 1280x1024@60Hz
	1366x768@60Hz, 1400x1050@60Hz, 1600x1200@60Hz
	VGA (RGB)
	800x600@60Hz, 1024x768@60Hz, 1280x1024@60Hz
	1366v768@60Hz 1400v1050@60Hz 1600v1200@60Hz
	1200x700@00112, 1400x1050@00112, 1000x1200@00112
Supported Video	1080р60/59.94/50, 1080р30/29.97/25/24/23.98
Output Format	1080i60/59.94/50, 720p60/59.94/50
	525i, 625i

	HDMI (YUV)			
	4096x2160p60/59.94/50			
	4096x2160p30/29/25/24/23.98			
	3840x2160p60/59.94/50			
	3840x2160p30/29.97/25/24/23.98			
	1080p60/59.94/50, 1080p30/29.97/25/24/23.98			
	1080i60/59.94/50, 720p60/59.94/50			
	480p, 576p, 480i, 576i			
Midea Decesso	SDI: YUV422			
Video Process	HDMI: YUV422/YUV444/RGB444/YUV420(4K only)			
Supported Audio Format	Input			
	Unbalanced Audio L/R : stereo audio			
	SDI embedded audio : up to 8ch, 48KHz, PCM audio			
	HDMI embedded audio : up to 8ch, 44.1/48/96KHz, PCM audio			
	Output			
	SDI embedded audio : up to 8ch, 48KHz, PCM audio			
	HDMI embedded audio : up to 8ch, 48KHz, PCM audio			
	Audio lock ofter conversion			
Frame Delay	I: 2~3 fields			
	P: 0~1 frames.			
Features				
Cross Reference	1			
Plug & Play	✓			
General				
Settings Control	Dip Switch			
Power Supply	DC 12V / 1A (9.4W)			
Operating	0°C to 40°C (32°F to 104°F)			
Temperature	100/ += 000/			
Dimensions (mm)				
Dimensions (mm)	220 X 145.5 X 42			
weight				
Certification				

Audio Input and Output Level				
	HDMI	SDI	Note	
INT (-20 dBFS)	-20 dBFS	-20 dBFS		
INT (0 dBFS)	0 dBFS	0 dBFS		
RCA-IN EXT (-14dBV)	-24 dBFS	-24 dBFS	SMPTE	
RCA-IN EXT (-14dBV)	-18 dBFS	-18 dBFS	EBU	

## Service & Support

It is our goal to make owning and using Datavideo products a satisfying experience. Our support staff is available to assist you to set up and operate your system. Contact your local office for specific support requests. Plus, please visit www.datavideo.com to access our FAQ section.



Datavideo Technologies China Co 902. No. 1 business building. Xiangtai Square. No. 129. Yingxiongshan Road, Shizhong District, Jinan City, Shandong Province, China Tei: +86 531-8607 8813 E-mail:service@datavideo.cn Datavideo Hong Kong Ltd G/F.,26 Cross Lane Wanchai, Hong Kong

Tel: +852-2833-1981 Fax:+852-2833-9916 E-mail:info@datavideo.com.hk

Datavideo India Noida A-132, Sec-63,Noida-201307, India

Tel: +91-0120-2427337 Fax:+91-0120-2427338 E-mail: sales@datavideo.in

Datavideo India Kochi 2nd Floor- North Wing, Govardhan Building, Opp. NCC Group Headquaters, Chittoor Road, Cochin-682035 Tel: +91 4844-0275336 Fax:+91 4844-027536 E-mail: sales@datavideo.in

 Datavideo Technologies Europe BV Floridadreef 106 3656 AM Utrecht, Tel: 431-30-261-96-56 Fax: 431-30-261-96-56 Fax: 431-30-261-96-57 E-mail:info@datavideo.nl
 Datavideo Visual Technology(S) Pte I tid

No. 178 Paya Lebar Road #06-07 Singapore 409030

Tel: +65-6749 6866
 Fax:+65-6749 3266
 E-mail:info@datavideovirtualset.com

Datavideo Technologies (S) PTE Ltd No. 178 Paya Lebar Road #06-03 Singapore 409030

Tel: +65-6749 6866 Fax:+65-6749 3266 E-mail:sales@datavideo.sg

Datavideo Technologies Co. Ltd 10F. No. 176, Jian 1st Rd., Chung Ho District, New Taipei City 235, Taiwan

Tel: +886-2-8227-2888 Fax:+886-2-8227-2777 E-mail:service@datavideo.com.tw

Datavideo Corporation 7048 Elmer Avenue. Whittier, CA 90602, U.S.A. Tel: +1-562-696 2324 Fax:+1-562-698 6930 E-mail:sales@datavideo.com

Datavideo UK Limited Brookfield House, Brookfield Industrial Estate, Peakdale Road, Glossop, Derbyshire, SK13 6LQ Tei: +44-1457 851 900 Fax:+44-1457 850 964 E-mail:sales@datavideo.co.uk

Datavideo France s.a.r.l. Cité Descartes 1, rue Albert Einstein Champs sur Marne 774477 – Marne la Vallée cedex 2 Tel: +33-1-60370246 Fax:+33-1-60376732 E-mail:info@datavideo.fr



Please visit our website for latest manual update. www.datavideo.com/product/DAC-45



All the trademarks are the properties of their respective owners. Datavideo Technologies Co., Ltd. All rights reserved 2018

Jan-31.2018 Version : E4