



Swivel Desk/S60
Assembly Instructions

Follow these instructions for the successful assembly your Bouncepad Swivel Desk/S60.




Sheet Code: BP-OR-IM-022_REV2
Release Date: 24/07/2019

Copyright 2016 Spotspot Ltd. (T/A Bouncepad) all rights reserved.
Confidential, no part of this publication may be reproduced or transmitted in any form without the written permission of the copyright holder.





0 In the box

0 Tools Required




#1 Configure the angle of rotation - ensuring both arrows are pointing in the same direction before starting. Default angle configuration is 270°. Insert the limit screws for 90° or 180° rotation.

#2 Attach your chosen mounting arm. Your mounting arm must forward lean in the same direction as the two arrows. Tighten by hand, ensuring full and correct engagement.




#3 Using the template (see A4) mark and drill the mounting holes appropriate to your mounting surface and cable routing configuration.

#4 Use the above template to mark the drill holes - appropriate to your chosen fixing method. 'A' if fixing from above. 'B' if fixing from below. Follow the corresponding steps (PTO) specific to each fixing method.




#5

If routing your tablet cable atop the mounting surface, feed it through the Mounting Arm as shown.




A1

Fixing From Above:
Lift & hold the rubber screw covers.
Use caution to not scratch the parts.




A2

Fixing From Above:
Secure the base with the 4x screws.
Close the screw covers once finished.




B1

Fixing From Below:
Screw in the 4x Socket Set Screws.
Ensure full thread engagement.




B2

Secure to the surface. Nylocs provide higher security whilst Wing Nuts allow for easier removal.




#6

Installation of the mounting arm is complete. Now install your Case as shown above.



#7

Install the Tablet Setup Kit. Each kit is specific per tablet device and Bouncepad Case.



#8

Route your tablet cable through the Case. Install the tablet into the Case and connect to power.



#9

Locate and lock the Faceplate to the Case.