


1-Port PCIe 2.5GBase-T Ethernet PoE Network Adapter Card - Intel

Product ID

PR12GIP-NETWORK-CARD



	Port/LED/Connector	Function
1	Bracket	<ul style="list-style-type: none"> Secures the card to the Host Computer Case <ul style="list-style-type: none"> The Full Pro le Bracket comes pre-installed The Low Pro le Bracket is included
2	Power Over Ethernet (PoE) LED Indicator	<ul style="list-style-type: none"> Solid Green: PoE has been negotiated and power is being supplied to the Powered Device O : No power output has been negotiated
3	Ethernet Port	<ul style="list-style-type: none"> Connect an Ethernet Cable to the Network Card Supports 2.5Gbps, 1Gbps, 100Mbps, and 10Mbps Supports IEEE 802.3at and IEEE 802.3af Right LED Indicator is Link Speed <ul style="list-style-type: none"> Solid Green: 2.5Gbps Solid Amber: 1Gbps O : 10/100Mbps Left LED Indicator is Link Status <ul style="list-style-type: none"> Solid Green: Active link Flashing Green: Activity

4	PCIe 2.0 x1 Connector	<ul style="list-style-type: none"> Insert into a PCI Express Slot on the Host Computer
5	SATA Power Connector	<ul style="list-style-type: none"> Connect SATA Power from the Host Computer's Power Supply <ul style="list-style-type: none"> Required to enable Power over Ethernet (PoE)

Package Contents

- Network Card x 1
- Low Pro le Bracket x 1
- Quick-Start Guide x 1

Requirements

For the latest requirements, please visit: www.StarTech.com/PR12GIP-NETWORK-CARD

- Host Computer with an available PCI Express 2.0 or greater slot (x1, x4, x8, or x16)

Installation

Install the PCI Express Card

WARNING! Static Electricity can severely damage **PCI Express Cards**. Ensure that you are adequately **Grounded** before you open your **Host Computer Case** or touch the **PCI Express Card**. You should wear an **Anti-Static Strap** or use an **Anti-Static Mat** when installing any **Host Computer** component. If an **Anti-Static Strap** isn't available, discharge any built-up static electricity by touching a large **Grounded Metal Surface** for several seconds. Only handle the **PCI Express Card** by its edges and don't touch the gold connectors.

1. Turn o the **Host Computer** and any **Peripheral Devices** that are connected to it (e.g. printers, external hard drives, etc.).
2. Unplug the **Power Cable** from the back of the **Host Computer**.
3. Disconnect any **Peripheral Devices** that are connected to the **Host Computer**.
4. Remove the **Cover** from the **Host Computer Case**.

Note: Consult the documentation that came with the **Host Computer** for details about doing this safely.

5. Locate an open **PCI Express Slot** and remove the corresponding **Slot Cover Plate** from the back of the **Host Computer Case**.

6. Gently insert the **PCI Express Card** into the open **PCI Express Slot** and fasten the **Bracket** to the back of the **Host Computer Case**.

Note: If you install the **PCI Express Card** into a **Small Form Factor** or a **Low Profile Desktop System**, it may be necessary to replace the pre-installed standard **Full Profile Bracket** with the included **Low Profile Bracket**.

7. Connect **SATA Power** from the **Host Computer's Power Supply** to the **SATA Power Connector** on the rear of the **Network Card**.

Note: If the **SATA Power** is not connected to the **Network Card**, **Power over Ethernet (PoE)** will be unavailable, but a data connection will still be established.

8. Reinstall the **Cover** on the **Host Computer Case**.
9. Reconnect the **Power Cable** to the **Host Computer**.
10. Reconnect all of the **Peripheral Devices** disconnected in **Step 3**.
11. Power on the **Host Computer** and connected **Peripheral Devices**.
12. Connect an **Ethernet Cable** to the **Ethernet Port** on the **Network Card**.

Download the Driver

1. Navigate to: www.StarTech.com/PR12GIP-NETWORK-CARD
2. Click the **Drivers & Downloads** tab.
3. Under **Driver(s)**, download the **Driver Package** for Windows.

Note: Windows usually saves the files to the Downloads folder associated with the user account (e.g. C:\Users\useraccount\Downloads).

Regulatory Compliance

FCC - Part 15

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by StarTech.com could void the user's authority to operate the equipment.

Industry Canada Statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada.

CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Warranty Information

This product is backed by a two year warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

4. **Right-click** the zipped **Driver Package** that was downloaded. Click **Extract All**. Follow the on-screen instructions to **Extract** the files.

Note: Ensure to make a note of the location where the drivers were extracted. That location will be used in later steps.

5. Follow the instructions on the accompanying **Intel_Windows_DIG** file for further **Installation Instructions**.

Verify the Driver Installation

Windows

1. Navigate to the **Device Manager**.
2. Under **Network Adapters**, right-click **Intel Ethernet Controller I225-V** and click the **Properties** option.
3. Confirm that the **Driver** is installed and working as expected.

Linux

Note: Ensure kernel 5.8 or higher is being used. Execute the following command from the terminal prompt to check the kernel version, `uname -r`.

1. Open a **Terminal Window** and type the command `sudo dmesg | grep Intel` to check the **Intel Driver Integration**.
2. If the drivers are present, the following entry should be present: **Intel(R) 2.5G Ethernet Linux Driver**.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Safety Measures

- Read the entire manual and ensure the instructions are fully understood before assembling and/or using this product.

Mesures de sécurité

- Assemblez ce produit conformément aux instructions.

安全対策


- 必ず取扱説明書に従って本製品の組み立てを行って下さい。

Misure di sicurezza

- Assicurarvi di Assemblare il prodotto secondo le istruzioni.

Säkerhetsåtgärder

- Se till att du monterar produkten i enlighet med instruktionerna



StarTech.com Ltd.
45 Artisans Crescent
London, Ontario
N5V 5E9
Canada

StarTech.com LLP
4490 South Hamilton
Road
Groveport, Ohio
43125
U.S.A.

StarTech.com Ltd.
Unit B, Pinnacle 15
Gowerton Road
Brackmills,
Northampton
NN4 7BW
United Kingdom

StarTech.com Ltd.
Siriusdreef 17-27
2132 WT Hoofddorp
The Netherlands

FR: startech.com/fr
DE: startech.com/de
ES: startech.com/es
NL: startech.com/nl
IT: startech.com/it
JP: startech.com/jp