


PCIe 2.0 to 4 PCIe Slots Expansion Chassis - USB Type-C

Product Diagram (4PCIE-PCIE-ENCLOSURE)


Expansion Chassis



	Port/LED/ Connector	Function
1	PCIe Expansion Slots	 Install up to Four PCle cards PCle version 2.0 x1 slots 5 Gbps downstream Full length cards supported
2	Mounting Brackets	 (Optional) Allows for a permanent installation of the Expansion Chassis to a at and stable surface Mounting Holes at the Front and Back of the Expansion Chassis secure the Mounting Brackets
3	On/O Switch	 Turns the Expansion Chassis On or O The correct sequence to power the device: Power on: Power On the Expansion Chassis rst, then the Host Computer Power o : Power O the Host Computer rst, then the Expansion Chassis
4	DC Power Port	 Connect the Expansion Chassis to a Power Source using the included Power Adapter Recommended 12 V and 3 A. Supports 12 to 24 V input
5	USB Type-C Connector	 Used to connect the Expansion Chassis to a Host Computer If the USB Type-C Cable is disconnected during use, the Host Computer must be restarted to reestablish the connection For a secure and correct cable connection, threaded holes around the USB Type-C Connector allow to Screwlock the included USB Type-C Cable
6	USB Type-C LED Indicator	 Indicates if the included USB Type-C-Cable is on the correct orientation. The cable is not reversible Solid Green = Correct orientation
7	Power LED Indicator	 Indicates if the On/O Switch is turned On or O Solid Red = On O = O
8	Terminal Block Connector	 Connect the Expansion Chassis to a DC Power Source Recommended 12 V and 3 A. Supports 12 to 24 V input
9	Metal Cover	Remove the Metal Cover to install the PCle cards

*Product may vary from image

PCIE Host Adapter Card



	Port/LED/ Connector	Function	
1	Bracket	Secures the card to the Computer Case. The Full height Bracket comes pre-installed	
2	USB Type-C Connector	 Used to connect the PCIE Host Card to the Expansion Chassis For a secure and correct cable connection, threaded holes around the USB Type-C Connector allow to Screwlock the included USB Type-C Cable 	
3	LP4 Power Connector	Optional: connect the Host Computer Power Supply	
4	SATA Power Connector	Optional: connect the Host Computer Power Supply	
5	PCle x2 Connector	Insert into a PCI Express Slot	

Package Contents

- PCle to PCle Expansion Chassis x 1
- PCle Host Adapter Card
- 6ft (1.8m) USB Type-C to C Male to Male Cable x 1
- · Low-Pro le Bracket x 1
- Power Adapter x 1
- Terminal Block Connector x 1
- Mounting Brackets x 2
- Mounting Brackets Screws x 4
- · Quick-Start Guide x 1

Requirements

For the latest requirements, please visit www.startech.com/4PCIE-PCIE-ENCLOSURE

- Computer with an available PCI Express slot (x2, x4, x8, or x16)
- Phillips head screwdriver

Installation

WARNING!

Static electricity can severely damage the PCle card(s) ensure that you are adequately grounded before you open your computer case or touch the PCle card(s). You should wear an anti-static strap or use an anti-static mat when installing any computer component. If an anti-static strap isn't available, discharge any built-up static electricity by touching a large grounded metal surface for several seconds. Only handle the PCle card(s) by the edges and don't touch the golden connectors.

Install the PCIe Host Adapter Card

- 1. Turn **O** the **Computer** and any **Peripheral Devices** that are connected to it (for example, **Printers**, **External Hard Drives**, etc.).
- 2. Unplug the **Power Cable** from the back of the **Computer**.
- 3. Disconnect any **Peripheral Devices** that are connected to the **Computer**.
- 4. Remove the **Cover** from the **Computer Case**. Consult the documentation that came with the **Computer** for details about doing this safely.
- 5. Locate an available PCI Express Slot and remove the corresponding Slot Cover Plate from the back of the Computer Case. Consult the documentation that came with the Computer for details about doing this safely. The PCIe Host Adapter Card works in PCI Express x2, x4, x8, or x16 Slots.
- 6. Gently insert the PCIe Host Adapter Card into the PCI Express Slot and fasten the Bracket to the back of the Computer Case.

Note: If you install the PCIe Host Adapter Card into a small form factor or a low-pro le desktop system, it may be necessary to replace the pre-installed standard full-height bracket with the included low-pro le bracket.

- 8. (Optional) Connect a **SATA Power Cable** or **LP4** from the **Host Computer Power Supply**.
- 9. Return the **Cover** onto the **Computer Case**.
- 10. Reconnect the **Power Cable** to the back of the **Computer**.
- 11. Reconnect all of the **Peripheral Devices** disconnected in **Step 1**.
- 12. Turn On the Computer and Peripheral Devices.

Install PCI Express Cards in the Expansion Chassis

Sharp edges! Be mindful of the sharp edges around the Expansion Chassis when the Metal Cover is removed.

- 1. Turn **O** the **Expansion Chassis** and unplug all cable connections.
- 2. Turn O the Host Computer.
- Release the Metal Cover by removing the Screws (x 12) using a Phillips Head Screwdriver. There are Screws on top and the side opposite to the connectors on the Expansion Chassis.
- Locate an available PCI Express Slot on the Expansion Chassis, using a Phillips
 Head Screwdriver remove the corresponding Slot Cover Plate from the Expansion
 Chassis.
- Gently insert the PCI Express Card (s) into the PCI Express Slot and fasten the Bracket to the Expansion Chassis. The Expansion Chassis supports PCI Express Cards x1 only.
- 6. Install the **Metal Cover** back onto the **Expansion Chassis**.
- 7. Screw-Lock the USB Type-C Cable onto the Expansion Chassis and the PCle Host Adapter Card on the Host Computer. This ensures the correct cable orientation.
- 8. Connect the **Power Adapter** or use the optional **Terminal Block Connector** to supply power. Turn **On** the **Expansion Chassis** by ipping the **On/O Switch**.
- 9. Turn On the Host Computer.

No drivers are needed for the Expansion Chassis. Some PCI Express Cards may need drivers to nish their installation.

Regulatory Compliance

FCC - Part 15

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installated and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment o and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Connect the equipment into an outlet on a circuit di erent from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modications not expressly approved by StarTech.com could void the user's authority to operate the equipment.

Industry Canada Statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada.

CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Warranty Information

This product is backed by a two-year warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

(Optional) Install the Mounting Brackets

- 1. Use the Mounting Screws (x 2) and Phillips Head Screwdriver to fasten the Front Mounting Bracket on the Expansion Chassis.
- 2. Repeat **Step 1** to install the **Rear Mounting Bracket**.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their o cers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of prots, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Safety Measures

Read the entire manual and ensure the instructions are fully understood before assembling and/or using this product.

Mesures de sécurité

 Lisez tout le manuel et assurez-vous que vous comprenez les instructions avant de commencer à assembler et utiliser ce produit

安全対策

最初に取扱説明書を最後まで読み、本製品の組み立て方をすべて理解してから組み立て作業を始めて下さい。

Misure di sicurezza

 Leggere l'intero manuale e assicurarsi di aver compreso tutte le istruzioni prima di iniziare ad assemblare e a utilizzare questo prodotto.

Säkerhetsåtgärder

• Läs hela manualen och se till att du förstår instruktionerna innan du börjar montera och använda produkten.

StarTech.com Ltd.

45 Artisans Crescent London, Ontario N5V 5E9 Canada

StarTech.com LLP

4490 South Hamilton Road Groveport, Ohio 43125 U.S.A.

StarTech.com Ltd.

Unit B, Pinnacle 15 Gowerton Road Brackmills, Northampton NN4 7BW United Kingdom

StarTech.com Ltd.

Siriusdreef 17-27 2132 WT Hoofddorp The Netherlands FR: startech.com/fr DE: startech.com/de ES: startech.com/es NL: startech.com/nl IT: startech.com/it JP: startech.com/jp