



Cleaning Protocol for Kensington Products that Meet MIL-STD-810H Method 504.3 Contamination by Fluids

Any Kensington product that meets the MIL-STD-810H Method 504.3 Contamination by Fluids testing is able to be wiped down or cleaned with a wide variety of cleaners, disinfectants and solvents, including alcohol and bleach without affecting the product.

What does it mean to meet the MIL-STD-810H Method 504.3 Contamination by Fluids Procedure?

The tested product is exposed, with continuous contact, to each chemical listed for at least 24 hours (unless otherwise specified), and exhibits no signs of degradation.

Chemicals that have been tested and approved for cleaning without causing degradation of the product include:

- Isopropyl alcohol (70%-75%)
- Accelerated Hydrogen Peroxide (Oxivir or Alpha HP)
- Orthophenylphenol (Amphyl, Reckitt Benckiser)
- Ortho-benzyl-parachlorophenol (Clorox Disinfectant Cleaner, The Clorox Company)
- Denatured alcohol (Hand Sanitizers with 60%-70% Isopropyl/Ethyl Alcohol)
- Lysol disinfectant
- Sani-Cloth HB, Plus and AF3
- Super Sani-Cloth Germ/Disp Wipes
- Cavi Wipes
- Clorox Healthcare Bleach Germicidal Wipes
- PDI Easy screen cleaning pad (alcohol)
- 409 Antibacterial All purpose Cleaner
- Windex Electronic Wipes

What does “no degradation” of the product mean?

- No visual defects
- No material degradation
- No discoloration
- No cracks
- No impact on use or function of the product



Cleaning Protocol for Kensington Products that Meet MIL-STD-810H Method 504.3 Contamination by Fluids

Recommended Cleaning Instructions:

Use damp cloth or sponge with preferred cleaning agent and wipe down product. Repeat cleaning process as needed. Do not oversaturate or submerge product in cleaning agent as damage could occur. Kensington evaluated a wide variety of cleaners and disinfecting solutions, but cannot guarantee that no degradation will occur using alternate cleaners or disinfection solutions not mentioned on the previous page.

If you have further questions on how to clean your Kensington products, please contact your local tech support.

US, Canada: 1-800-535-4242

Sweden: 46 08 50 33 65 772

Great Britain: +44 (0)203 364 5390

New Zealand: +64 0800 539 262

Denmark: 45 80 25 09 6

Australia: 1300 881 931

Finland: 358 0800 9 15697

Japan: 04-7129-2135

Ireland: 353 01 431 1395

China: 400 600 4599

Norway: 47 800 175 20

Brazil: 800855802

Portugal: 351 800855802

Mexico: 911 146 735

