

PRO Series

LCD Monitor

PRO MP273U (3PB4)

User Guide

Contents

Getting Started	3
Package Contents	3
Installing the Monitor Stand	4
Adjusting the Monitor	5
Monitor Overview	6
Connecting the Monitor to PC	8
OSD Setup	9
OSD Keys	9
OSD Menus	10
Professional	10
Image	12
Input Source	13
PIP/PBP	14
Navi Key	15
Settings	15
Specifications	17
Preset Display Modes	19
Troubleshooting	20
Safety Instructions	21
TÜV Rheinland Certification	23
ENERGY STAR Certification	23
Regulatory Notices	24

Revision

V1.0, 2024/05

Getting Started

This chapter provides you with the information on hardware setup procedures. While connecting devices, be careful in holding the devices and use a grounded wrist strap to avoid static electricity.

Package Contents

Monitor	PRO MP273U		
Documentation	Quick Start Guide		
	Stand		
	Stand Base		
Accessories	Power Cord		
	External Power Supply		
Cables	High Speed HDMI™ Cable (Optional)		




/ Important

- Contact your place of purchase or local distributor if any of the items is damaged or missing.
- Package contents may vary by country.
- The included power cord is exclusively for this monitor and should not be used with other products.

Installing the Monitor Stand

- 1. Leave the monitor in its protective packaging. Align and gently push the stand bracket towards the monitor groove until it locks in place.
- 2. Align and gently push the base towards the stand until it locks in place.
- 3. Make sure the stand assembly is properly installed before setting the monitor upright.





Important

- Place the monitor on a soft, protected surface to avoid scratching the display panel.
- Do not use any sharp objects on the panel.
- The back of the monitor can also be used for wall mount. Please contact your dealer for proper wall mount kit.
- This product comes with NO protective film to be removed by the user! Any
 mechanical damages to the product including removal of the polarizing film may
 affect the warranty!




Adjusting the Monitor

This monitor is designed to maximize your viewing comfort with its adjustment capabilities.




Important

- Avoid touching the display panel when adjusting the monitor.
- Please slightly tilt the monitor backwards before pivoting it.




Monitor Overview



0	OSD Keys
2	Power Button & Power LED
6	Lit in white after the monitor is turned on. If no signal input, the LED will turn into orange. Lit in orange when the monitor is in Stand-by mode.
3	DisplayPort
	Supports 3840x2160@60Hz as specified in DisplayPort 1.4a.
4	HDMI™ Connector HDMI ™
	Supports HDMI™ CEC, 3840x2160@60Hz as specified in HDMI™ 2.0b.
6	HDMI™ Connector H⊃ I
	Supports 3840x2160@60Hz as specified in HDMI™ 2.0b.
6	Headphone Jack
7	Power Jack
8	Kensington Lock

Connecting the Monitor to PC

- 1. Turn off your computer.
- 2. Connect the video cable from the monitor to your computer.
- **3.** Assemble the external power supply & power cord. (Figure A)
- **4.** Connect the external power supply to the monitor power jack. (Figure B)
- **5.** Plug the power cord into the electrical outlet. (Figure C)
- **6.** Turn on the monitor. (Figure D)
- 7. Power on the computer and the monitor will auto detect the signal source.



OSD Setup

This chapter provides you with essential information on OSD Setup.




/ Important

All information is subject to change without prior notice.


OSD Keys

The monitor comes with a set of OSD Keys that help to control the On-Screen Display (OSD) menu.



OSD Key	Hot Key (When OSD is OFF)	OSD Setup (When OSD is ON)	
М	Activating the OSD Main Menu	Entering the submenus. Confirming a selection or setting.	
◀	• Mode		
•	Input Source		
Е	Audio Volume		

OSD Menus





Important

The following settings will be grayed out when HDR signals are received:

- Low Blue Light
- HDCR
- Brightness

- Contrast
- Color Temperature

Professional

1st Level Menu	2nd/3rd Level Menu	Description		
Mode	Eco	Use Left or Right Button to select and preview		
	User	mode effects. • Press the E Button to confirm and apply your		
	sRGB	mode type.		
	Anti-Blue	The default setting "Eco" mode meets the requirements of TÜV Rheinland's "Low Blue		
	Movie	Light" standard and Eyesafe certification.		
	Office	Activating sRGB will affect:		
	Black-White	Affected Function Function Status Color Temperature Low Blue Light Unable to select Contrast		
Response Time	Normal	Setting to Fastest will reach the shortest		
	Fast	response time and help improve blurred images when playing very fast games.		
	Fastest			

1st Level Menu	2nd/3rd Lev	el Menu	Description		
Refresh Rate	Location	Left Top		e in OSD Menu. Press the E	
	Right Top Button to confirm and apply your Location.	d apply your Refresh Rate			
Left Bot		Left Bottom	This monitor follows and works at the Operati		
		Right Bottom	System's preset Screen Refresh Rate.		
	OFF				
	ON				
Alarm Clock	Location	Left Top	After setting the time	, press the E Button to	
		Right Top	activate the timer.Users have to manua	lly restore their preset	
		Left Bottom	Alarm Clock after any reconnection.		
		Right Bottom	reconnection.		
	OFF				
	15:00	00:01 ~ 99:59			
	30:00				
	45:00				
	60:00				
Eye-Q Check	OFF		Select OFF to disable Eye-Q Check.		
			Activating Eye-Q Check will affect:		
			Affected Function	Function Status	
			» Info. On Screen	Set to OFF	
	Amsler Grid		Select Amsler Grid to check your central vision field. Select Astigmatism to check your blurred vision.		
	Astigmatism	1			
	Posture Cor	rection	Select Posture Corre posture when sitting.	ction to improve your	
Screen Assistance	None		Users can adjust Screen Assistance in any	een Assistance in any	
	[+] [+] ++ -+- ++ -+- ++- ++- × × 2^3 2^3 (3) (3)		mode.		

1st Level Menu	2nd/3rd Level Menu	Description	
Screen Size	Auto	resolution and any screen refresh rate.	
	4:3		
	16:9		
Adaptive-Sync	OFF	Adaptive-Sync prevents screen tearing.	
	ON • Activating Adaptive-Sync will affect		ync will affect:
		Affected Function	Function Status
		» PIP/PBP	Set to OFF

Image

1st Level Menu	2nd/3rd Level Menu	Description	
Brightness	0-100	Properly adjust Brightne surrounding lighting.	ess according to the
Contrast	0-100	Properly adjust Contrast	t to relax your eyes.
Sharpness	0-5	Sharpness improves cla images.	rity and details of
Image	OFF	Image Enhancement enl	
Enhancement	Weak	improve their acutance.	
	Medium		
	Strong		
	Strongest		
Low Blue Light	OFF	Low Blue Light protects your eyes against light. When enabled, Low Blue Light adjust the screen color temperature to a more ye glow.	
	ON		
		When Mode is set to Ant to enable Low Blue Ligh	,
		This monitor is a Low Bl will decrease the blue li adjusting the OSD settin	ght emitted without
HDCR	OFF	HDCR enhances image quality by increasing	
	ON contrast of images. • Activating HDCR will		ect:
		Affected Function F	Function Status
		» Brightness L	Jnable to select

1st Level Menu	2nd/3rd Level Menu		Description
Color Temperature	Cool		Use Left or Right Button to select and preview
	Normal		mode effects. • Press the E Button to confirm and apply your
	Warm		mode type.
	Customization	R (0-100)	Users can adjust Color Temperature in Customization mode.
		G (0-100)	
		B (0-100)	

Input Source

1st Level Menu	2nd Level Menu	Description
HDMI™ 1		Select an Input Source from the list.
HDMI™ 2		
DP		
Auto Scan	OFF	Users can use the Navi Key to select Input Source at below status:
	ON	While "Auto Scan" is set to "OFF" with the monitor at power saving mode;
		While "No Signal" message box is shown on the monitor.

PIP/PBP

1st Level Menu	2nd/3rd Level Menu		Description		
OFF		PIP (Picture in Picture) allows users to simultaneously display multiple video sources			
PIP	Source			ogram is displayed on the	
		HDMI™2		ne time as one or more displayed in inset windows.	
		DP	PBP (Picture by Picture)	ıre) is a similar feature	
	PIP Size	Small	that displays two inputes the screen.	ut sources side-by-side on	
		Medium		s users to switch between	
		Large	primary and seconda • If there is only one si	, ,	
	Location	Left Top	Switch and Audio Sw	itch will be grayed out.	
		Right Top	Activating PIP/PBP w		
		Left Bottom	Affected Function	Function Status	
		Right Bottom	» Response Time » DisplayHDR	Unable to select	
	Display Swit	ch	» MPRT	Set to 0FF	
	Audio Switcl	n	» Adaptive-Sync		
PBP	Source 1	HDMI™1	» HDMI™ CEC	Set to OFF & unable to select	
		HDMI™2	» PIP/PBP: Screen	Set to Auto & unable to select	
		DP	Size	to select	
	Source 2	HDMI™1			
		HDMI™2			
		DP			
	Display Switch				
	Audio Switcl	า			

Navi Key

1st Level Menu	2nd Level Menu	Description
Enter	0FF	All Navi Key items can be adjusted via OSD Menus.
Left	Brightness	
Right	Mode	
	Alarm Clock	
	Input Source	
	Refresh Rate	
	Info. On Screen	
	Audio Volume	

Settings

1st Level Menu	2nd Level Menu	Description
		•
Language	繁體中文	Users have to press the E Button to confirm and apply the Language setting.
	English	Language is an independent setting. Users' own
	Français	language setting will override the factory default. When users set Reset to Yes, Language will not be changed.
	Deutsch	users set reset to res, Language witt not be changed.
	Italiano	
	Español	
	한국어	
	日本語	
	Русский	
	Português	
	简体中文	
	Bahasa Indonesia	
	Türkçe	
	(More languages coming soon)	
Transparency	0~5	Users can adjust Transparency in any mode.
OSD Time Out	5~30s	Users can adjust OSD Time Out in any mode.
Power Button	OFF	When set to OFF, users can press the power button to turn off the monitor.
	Standby	When set to Standby, users can press the power button to turn off the panel and backlight.

1st Level Menu	2nd Level Menu	Description	
HDMI™ CEC	OFF	HDMI TM CEC (Consumer Electronics Control) supports	
	ON	Sony PlayStation®, Nintendo® Switch™, Xbox Series X S consoles and various audio-visual devices that are CEC-capable.	
		If HDMI™ CEC is set to 0N:	
		The monitor will automatically power on when the CEC device is turned on.	
		The CEC device will enter power saving mode when the monitor is turned off.	
		 When Sony PlayStation®, Nintendo® Switch™, or Xbox Series XIS console is connected, Game Mode and Pro Mode will be automatically set to default modes and can be adjusted to users' preferred modes later. 	
Info. On Screen	OFF	The information of the monitor status will be shown on	
	ON	the right side of the screen.	
Audio Volume	0-100	Users can adjust Audio Volume in any mode.	
Reset	YES	Users can Reset and restore settings to original OSD	
	NO NO	Default in any mode.	

Specifications

Monitor	PR0 MP273U		
Size	27 inch		
Curvature	Flat		
Panel Type	IPS		
Resolution	3840x2160 (UHD)		
Aspect Ratio	16:9		
Brightness	Typical SDR 300 nits		
Contrast Ratio	1000:1		
Refresh Rate	60Hz		
Response Time	4ms (GtG)		
1/0	DisplayPort x1		
	HDMI™ Connector x2		
	Headphone Jack x1		
View Angles	178°(H), 178°(V)		
DCI-P3*/ sRGB	98% / 130%		
Surface Treatment	Anti-glare		
Display Colors	1.07B (10bits + FRC)		
Speaker	3W x2		
Monitor Power Options	12V === 4A		
External Power Supply*	Model: ADS-40NP-12-1 12036E		
Power Input	100~240Vac, 50~60Hz, 1.5A Max		
Power Output	12V === 4A		
Adjustment (Tilt)	-5° ~ 20°		
Kensington Lock	Yes		
VESA Mounting	• Plate Type: 75 x 75 mm		
	• Screw Type: M4 x 10 mm		
	• Thread Diameter: 4 mm		
	• Thread Pitch: 0.7 mm		
	Thread Length: 10 mm		
Dimension (W x H x D)	613.50 x 462.60 x 181.10 mm		

Monitor		PR0 MP273U		
Weight	Net	3.9 Kg		
	Gross	6.2 Kg		
Environment	Operating	• Temperature: 0°C to 40°C		
		• Humidity: 20% to 90%, non-condensing		
Storage		• Altitude: 0 ~ 5000m		
		• Temperature: -20°C to 60°C		
		• Humidity: 10% to 90%, non-condensing		

^{*} Based on CIE1976 test standards.

Preset Display Modes



All information is subject to change without prior notice.

Ctondond	Resolution		Standard Mode	
Standard			HDMI™	DP
FHD	1920x1080	@60Hz	V	V
QHD	2560x1440	@60Hz	V	V
UHD	3840x2160	@60Hz	V	V
Video Timing Resolution	720P		٧	V
	1080P		V	V
	2160P	@50Hz	٧	V
	2160P	@60Hz	V	V
	HDMI™ VRR		٧	

Standard	Resolution		PIP Mode (Not Support HDR)	
Standard			HDMI™	DP
FHD	1920x1080	@60Hz	V	V
QHD	2560x1440	@60Hz	V	V
UHD	3840x2160	@60Hz	٧	٧
Video Timing Resolution	720P		٧	V
	1080P		٧	V
	2160P	@50Hz		
	2160P	@60Hz	٧	V

Standard	Resolution		PBP Mode (Not Support HDR)	
Standard			HDMI™	DP
FHD	1920x1080	@60Hz	٧	٧
Video Timing Resolution	720P		٧	٧
	1080P		٧	٧
PBP Timing	1920x1080	@60Hz	٧	٧

Troubleshooting

The power LED is off.

- Press the monitor power button again.
- Check if the monitor power cable is properly connected.

No image.

- Check if the computer graphics card is properly installed.
- Check if the computer and monitor are connected to electrical outlets and are turned on.
- Check if the monitor signal cable is properly connected.
- The computer may be in Standby mode. Press any key to activate the monitor.

The screen image is not properly sized or centered.

 Refer to Preset Display Modes to set the computer to a setting suitable for the monitor to display.

No Plug & Play.

- Check if the monitor power cable is properly connected.
- Check if the monitor signal cable is properly connected.
- Check if the computer and graphics card are Plug & Play compatible.

The icons, font or screen are fuzzy, blurry or have color problems.

- · Avoid using any video extension cables.
- · Adjust brightness and contrast.
- Adjust RGB color or tune color temperature.
- Check if the monitor signal cable is properly connected.
- Check for bent pins on the signal cable connector.

The monitor starts flickering or shows waves.

- Change the refresh rate to match the capabilities of your monitor.
- Update your graphics card drivers.
- Keep the monitor away from electrical devices that may cause electromagnetic interference (EMI).

Safety Instructions

- Read the safety instructions carefully and thoroughly.
- All cautions and warnings on the device or User Guide should be noted.
- Refer servicing to qualified personnel only.

Power

- Make sure that the power voltage is within its safety range and has been adjusted properly to the value of 100~240V before connecting the device to the power outlet.
- If the power cord comes with a 3-pin plug, do not disable the protective earth pin from the plug. The device must be connected to an earthed mains socket-outlet.
- Please confirm the power distribution system in the installation site shall provide the circuit breaker rated 120/240V, 20A (maximum).
- Always disconnect the power cord or switch the wall socket off if the device would be left unused for a certain time to achieve zero energy consumption.
- Place the power cord in a way that people are unlikely to step on it. Do not place anything on the power cord.
- If this device comes with an adapter, use only the MSI provided AC adapter approved for use with this device.

Environment

- To reduce the possibility of heat-related injuries or of overheating the device, do not place the device on a soft, unsteady surface or obstruct its air ventilators.
- Use this device only on a hard, flat and steady surface.
- To prevent the device from tipping over, secure the device to a desk, wall or fixed object with an anti-tip fastener that helps to properly support the device and keep it safe in place.
- To prevent fire or shock hazard, keep this device away from humidity and high temperature.
- Do not leave the device in an unconditioned environment with a storage temperature above 60°C or below -20°C, which may damage the device.
- The maximum operating temperature is around 40°C.
- When cleaning the device, be sure to remove the power plug. Use a piece of soft cloth rather than industrial chemical to clean the device. Never pour any liquid into the opening; that could damage the device or cause electric shock.
- Always keep strong magnetic or electrical objects away from the device.

- If any of the following situations arises, get the device checked by service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated into the device.
 - The device has been exposed to moisture.
 - The device does not work well or you can not get it working according to the User Guide.
 - The device has dropped and damaged.
 - The device has obvious sign of breakage.

TÜV Rheinland Certification

TÜV Rheinland Low Blue Light Certification

Blue light has been shown to cause eye fatigue and discomfort. MSI now offers monitors with TÜV Rheinland Low Blue Light certification to ensure users' eye comfort and well-being. Please follow the instructions below to reduce the symptoms from extended exposure to the screen and blue light.



- Place the screen 20 28 inches (50 70 cm) away from your eyes and a little below eye level.
- Consciously blinking the eyes every now and then will help to reduce eye strain after extended screen time.
- Take breaks for 20 minutes every 2 hours.
- Look away from the screen and gaze at a distant object for at least 20 seconds during breaks.
- Make stretches to relieve body fatigue or pain during breaks.
- Turn on the optional Low Blue Light function.

TÜV Rheinland Flicker Free Certification

 TÜV Rheinland has tested this product to ascertain whether the display produces visible and invisible flicker for the human eye and therefore strains the eyes of users.



- TÜV Rheinland has defined a catalogue of tests, which sets out minimum standards at various frequency ranges. The test catalogue is based on internationally applicable standards or standards common within the industry and exceeds these requirements.
- The product has been tested in the laboratory according to these criteria.
- The keyword "Flicker Free" confirms that the device has no visible and invisible flicker defined in this standard within the range of 0 3000 Hz under various brightness settings.
- The display will not support Flicker Free when Anti Motion Blur/MPRT is enabled.
 (The availability of Anti Motion Blur/MPRT varies by products.)

ENERGY STAR Certification

ENERGY STAR is a program run by the U.S. Environmental Protection Agency (EPA) and U.S. Department of Energy (DOE) to promote energy efficiency. This product qualifies for ENERGY STAR in the "factory default" settings through which power savings will be achieved. Changing the factory default picture settings or enabling other features will increase power consumption, which could exceed the limits necessary to qualify for ENERGY STAR rating.



For more information on ENERGY STAR, refer to https://www.energystar.gov/.

Regulatory Notices

CE Conformity

This device complies with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility [2014/30/EU], Low-voltage Directive (2014/35/EU), ErP Directive (2009/125/EC) and RoHS directive (2011/65/EU). This product has been tested and found to comply with the harmonized standards for Information Technology Equipment published under Directives of Official Journal of the European Union.

FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/television technician for help.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

MSI Computer Corp.

901 Canada Court, City of Industry, CA 91748, USA (626) 913-0828

www.msi.com

WEEE Statement

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2012/19/EU, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life.



Chemical Substances Information

In compliance with chemical substances regulations, such as the EU REACH Regulation (Regulation EC No. 1907/2006 of the European Parliament and the Council), MSI provides the information of chemical substances in products at: https://csr.msi.com/global/index

RoHS Statement

Japan JIS C 0950 Material Declaration

A Japanese regulatory requirement, defined by specification JIS C 0950, mandates that manufacturers provide material declarations for certain categories of electronic products offered for sale after July 1, 2006.

https://csr.msi.com/global/Japan-JIS-C-0950-Material-Declarations

India RoHS

This product complies with the "India E-waste (Management and Handling) Rule 2016" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

Turkey EEE Regulation

Conforms to the EEE Regulations of the Republic Of Turkey

Ukraine Restriction of Hazardous Substances

The equipment complies with requirements of the Technical Regulation, approved by the Resolution of Cabinet of Ministry of Ukraine as of 10 March 2017, \mathbb{N}^2 139, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment.

Vietnam RoHS


As from December 1, 2012, all products manufactured by MSI comply with Circular 30/2011/TT-BCT temporarily regulating the permitted limits for a number of hazardous substances in electronic and electric products.


Green Product Features

- Reduced energy consumption during use and stand-by
- Limited use of substances harmful to the environment and health
- Easily dismantled and recycled
- Reduced use of natural resources by encouraging recycling
- Extended product lifetime through easy upgrades
- Reduced solid waste production through take-back policy

Environmental Policy

- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away at its end of life.
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.





Warning!

Overuse of screens is likely to affect eyesight.

Recommendations:

- 1. Take a 10-minute break for every 30 minutes of screen time.
- 2. Children under 2 years of age should have no screen time. For children aged 2 years and over, screen time should be limited to less than one hour per day.

Copyright and Trademarks Notice

msi Msi 微星





Copyright © Micro-Star Int'l Co., Ltd. All rights reserved. The MSI logo used is a registered trademark of Micro-Star Int'l Co., Ltd. All other marks and names mentioned may be trademarks of their respective owners. No warranty as to accuracy or completeness is expressed or implied. MSI reserves the right to make changes to this document without prior notice.



The terms HDMI™, HDMI™ High-Definition Multimedia Interface, HDMI™ Trade dress and the HDMI™ Logos are trademarks or registered trademarks of HDMI™ Licensing Administrator, Inc.

Technical Support

If a problem arises with your product and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please visit https://www.msi.com/support/ for further guidance.

